

Easy UPS 3S

10-40 kVA 208 V

Operation

Latest updates are available on the Schneider Electric website
11/2023



Legal Information

The information provided in this document contains general descriptions, technical characteristics and/or recommendations related to products/solutions.

This document is not intended as a substitute for a detailed study or operational and site-specific development or schematic plan. It is not to be used for determining suitability or reliability of the products/solutions for specific user applications. It is the duty of any such user to perform or have any professional expert of its choice (integrator, specifier or the like) perform the appropriate and comprehensive risk analysis, evaluation and testing of the products/solutions with respect to the relevant specific application or use thereof.

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this document are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owner.

This document and its content are protected under applicable copyright laws and provided for informative use only. No part of this document may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the document or its content, except for a non-exclusive and personal license to consult it on an "as is" basis.

Schneider Electric reserves the right to make changes or updates with respect to or in the content of this document or the format thereof, at any time without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this document, as well as any non-intended use or misuse of the content thereof.



Find the manuals here:
Trouvez les manuels ici:
Encuentre los manuales aquí:



https://www.productinfo.schneider-electric.com/easyups3s_ul/

Table of Contents

Important Safety Instructions — SAVE THESE INSTRUCTIONS	7
FCC Statement	8
Safety Precautions	8
Overview	9
User Interface	9
Display Interface	11
Overview of Single UPS	12
Overview of Parallel System	12
Location of Breakers	14
Operation Modes	15
Operation Procedures	19
Initial Start-Up of the UPS Using the Wizard – Only Applicable to Single UPSs with Internal Batteries	19
Start-Up Checklist – Only Applicable to Single UPSs with Internal Batteries	20
Start Up a Single UPS in Normal Mode	20
Transfer a Single UPS from Normal Mode to Static Bypass Mode	22
Transfer a Single UPS from Static Bypass Mode to Normal Mode	23
Transfer a Single UPS from Normal Mode to Maintenance Bypass Mode	23
Transfer a Single UPS from Maintenance Bypass Mode to Normal Mode	24
Transfer a Parallel System from Normal Mode to Maintenance Bypass Mode	25
Transfer a Parallel System from Maintenance Bypass Mode to Normal Mode	26
Isolate a Single UPS from the Parallel System	27
Start Up and Add a UPS to a Running Parallel System	28
Start up the UPS from Cold Start	30
Shut down the UPS from Cold Start	30
Configuration	31
Register Your Easy UPS 3S	31
Set the Display Language	31
Set the Date and Time	32
Set the UPS Settings	32
Set the Battery Settings	33
Recommended Battery Settings	33
Set the Life Cycle Monitoring	36
Settings	36
Tests	38
Perform a Battery Maintenance Test	38
Perform a Battery Test	38
Maintenance	39
Parts Replacement	39
Determine if you need a Replacement Part	39
Replace the Dust Filter	39

Troubleshooting	41
View the Active Alarms.....	41
Buzzer	41
Status and Alarm Messages	41
View the Logs.....	45

Important Safety Instructions — SAVE THESE INSTRUCTIONS

Read these instructions carefully and look at the equipment to become familiar with it before trying to install, operate, service or maintain it. The following safety messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety message indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages with this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in death or serious injury.**

Failure to follow these instructions will result in death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in death or serious injury.**

Failure to follow these instructions can result in death, serious injury, or equipment damage.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in minor or moderate injury.**

Failure to follow these instructions can result in injury or equipment damage.

NOTICE

NOTICE is used to address practices not related to physical injury. The safety alert symbol shall not be used with this type of safety message.

Failure to follow these instructions can result in equipment damage.

Please Note

Electrical equipment should only be installed, operated, serviced, and maintained by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

Per IEC 62040-1: "Uninterruptible power systems (UPS) -- Part 1: Safety Requirements," this equipment, including battery access, must be inspected, installed and maintained by a skilled person.

The skilled person is a person with relevant education and experience to enable him or her to perceive risks and to avoid hazards which the equipment can create (reference IEC 62040-1, section 3.102).

FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Safety Precautions

DANGER

HAZARD OF ELECTRICAL SHOCK, EXPLOSION OR ARC FLASH

All safety instructions in this document must be read, understood and followed.

Failure to follow these instructions will result in death or serious injury.

DANGER


HAZARD OF ELECTRICAL SHOCK, EXPLOSION OR ARC FLASH

After the UPS system has been electrically wired, do not start up the system. Start-up must only be performed by Schneider Electric.

Failure to follow these instructions will result in death or serious injury.

Overview

User Interface



Keys

Home	Previous	Next	Confirm

EPO

Only use the EPO button in case of emergency.

It can be configured whether, when the EPO is activated, the UPS should:

- turn off the rectifier, inverter, charger, and static bypass and stop supplying the load immediately (default), or
- transfer to static bypass mode and continue supplying the load.


⚡ ⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

The UPS control circuit will remain active after the EPO has been pushed if utility/mains is available.

Failure to follow these instructions will result in death or serious injury.

Status LEDs




LED	Status
A	<p>Rectifier</p> <p>Green : Rectifier is working correctly.</p> <p>Flashing green : Rectifier is starting up.</p> <p>Red : Rectifier is inoperable.</p> <p>Flashing red : Utility/mains is unavailable.</p> <p>OFF : Rectifier is off.</p>
B	<p>Battery</p> <p>Green : Battery is charging.</p> <p>Flashing green : Battery is discharging.</p> <p>Red : Battery is inoperable.</p> <p>Flashing red : Battery low voltage.</p> <p>OFF : Battery and battery charger are OK, battery is not charging or discharging.</p>
C	<p>Bypass</p> <p>Green : Load supplied by bypass source.</p> <p>Red : Bypass source is unavailable or static bypass switch is inoperable.</p> <p>Flashing red : Bypass voltage is out of tolerance.</p> <p>OFF : Bypass source is OK.</p>
D	<p>Inverter</p> <p>Green : Load supplied by inverter.</p> <p>Flashing green : Inverter on, start, synchronization or standby (ECO mode).</p> <p>Red : Load not supplied by inverter, inverter is inoperable.</p>

	LED	Status
		Flashing red  : Load supplied by inverter, but an inverter alarm is present. OFF  : Inverter is off.
E	Load	Green  : UPS output is on. Red  : Overload on UPS output for too long, or output has shorted, or no output power present. Flashing red  : Overload on UPS output. OFF  : UPS output is off.
F	Status	Green  : UPS is OK. Red  : Inoperable status.

Display Interface

Home Screen




Buttons

							
Power On/ Off	Input and bypass status information	Output status information	Battery status information	UPS status	Function settings	Log	Mute

Overview of Single UPS

UIB	Unit input breaker
SSIB	Static switch input breaker
UOB	Unit output breaker
MBB	Maintenance bypass breaker
BB	Battery relay




Overview of Parallel System

NOTE: In parallel systems with an external maintenance bypass breaker Ext. MBB, the maintenance bypass breakers MBB must be padlocked in the open position.


MIB	Mains input breaker
BIB	Bypass input breaker
UIB	Unit input breaker
SSIB	Static switch input breaker
UOB	Unit output breaker
Ext. UOB	External unit output breaker
MBB	Maintenance bypass breaker
Ext. MBB	External maintenance bypass breaker
SIB	System isolation breaker
BB	Battery relay

Location of Breakers


10 kVA UPS




15-20 kVA UPS



30 kVA UPS



40 kVA UPS




Operation Modes


Normal Mode

The UPS provides power to the connected load from mains. The UPS converts mains to conditioned power for the connected load while recharging the batteries (float or boost charge).

LED Status





Power Flow



Battery Mode

The UPS transfers to battery mode if the mains supply fails. The UPS provides power to the connected load from the connected batteries for a finite period. When the mains supply returns, the UPS transfers back to normal mode.


LED Status




Static Bypass Mode

The UPS supplies the load with power from the bypass source. If the conditions for normal or battery mode are not met, the load will be transferred from the inverter to the bypass source with no interruption in power to the load.

LED Status




Power Flow




Maintenance Bypass Mode

In maintenance bypass mode, the mains is sent via the external MBB to the load. Battery backup is not available in maintenance bypass mode.

LED Status



Power Flow




ECO Mode


In ECO mode the UPS is configured to use static bypass mode as the preferred operation mode under predefined circumstances. The inverter is in standby in ECO mode and in case of interruption to the mains, the UPS transfers to battery mode and the load is supplied from the inverter.

NOTE: This mode is disabled by default, please contact Schneider Electric to enable this mode. If ECO mode is enabled, you cannot exit this operation mode by using the display, please also contact Schneider Electric for assistance.

LED Status



Power Flow



Autostart Mode

The batteries will reach end of discharge if the interruption to the mains is longer than the battery runtime. If the UPS is programmed to auto-restart after end of discharge, the system will automatically restart after a delay when the mains returns.


NOTE: If autostart is disabled, the inverter and bypass will not restart automatically when the mains return.

Frequency Converter Mode


In frequency converter mode, the UPS presents a stable output frequency (at 50 or 60 Hz) and the static bypass switch is not available.

NOTICE
<p>RISK OF EQUIPMENT DAMAGE OR LOAD DROP</p> <p>In frequency converter mode the UPS cannot run in static bypass or maintenance bypass mode. Before turning the UPS into frequency converter mode, you must contact a Schneider Electric-certified partner to make sure</p> <ul style="list-style-type: none"> • the SSIB and the MBB are in the OFF (opened) position (Schneider Electric strongly recommends to lock these with a padlock available from Schneider Electric) • no cables are connected to the bypass terminals <p>Failure to follow these instructions can result in equipment damage.</p>

LED Status



Power Flow



Operation Procedures

Initial Start-Up of the UPS Using the Wizard – Only Applicable to Single UPSs with Internal Batteries

⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Parallel systems and UPSs for external batteries must only be started up by Schneider Electric.

Failure to follow these instructions will result in death or serious injury.

Before starting up the UPS, confirm that:

- The room temperature is between 0 °C to 40 °C
- The UPS has been installed according to the specified clearance dimensions.

1. Turn the unit input breaker UIB to the ON (closed) position.
The display turns on.
2. Select to register the UPS or select **Skip** to continue. See Register Your Easy UPS 3S, page 31 for more information.
3. When the **Change language** prompt appears, do one of the following:
 - Select **Yes** and select the preferred language using the navigation keys. Select **Yes** again to confirm.
 - Select **No** to keep the current selection.
4. When the **Change voltage** prompt appears, do one of the following:
 - Select **Yes** and select the preferred voltage using the navigation keys. Select **Yes** again to confirm.
 - Select **No** to keep the current selection.
5. When the **Change freq.** prompt appears, do one of the following:
 - Select **Yes** and select the preferred output frequency using the navigation keys. Select **Yes** again to confirm.
 - Select **No** to keep the current selection.
6. When the **Change mode** prompt appears, do one of the following:
 - Select **Yes** and select **Normal mode**, **Parallel mode**, or **Frequency converter mode** using the navigation keys. Select **Yes** again to confirm.
 - Select **No** to keep the current selection.
7. When the **Change Batt setting** prompt appears, perform the following steps:
 - a. **Enter password:** Enter the password 2334.
 - b. **Batt number:** Verify the number of battery blocks is 20.
 - c. **Batt cap (AH):** Set the battery capacity to according to your battery configuration.
 - d. **Batt charge %:** Set the battery charge percentage (between 1% and 15%).
 - e. Select **Yes** to save the battery settings.
8. When the **Save new settings** prompt appears, select **Yes**.

9. When the **Disable wizard** prompt appears, do one of the following:

- Select **Yes** to disable the wizard and go to the default screen.

NOTE: Schneider Electric recommends to disable the wizard to allow for automatic start.

- Select **No** to go to the default screen without disabling the wizard.

Post-requisite: For systems with internal batteries, go to .

Start-Up Checklist – Only Applicable to Single UPSs with Internal Batteries

⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Parallel systems and UPSs for external batteries must only be started up by Schneider Electric.

Failure to follow these instructions will result in death or serious injury.

- I have positioned the UPS according to the installation manual and the recommended clearances are respected.
- I have verified that the environmental conditions including temperature, humidity, and airflow stated in the installation manual are respected.
- I have verified that the input voltage and frequency are within the tolerances specified in the installation manual.
- I have verified that the upstream protection is in accordance with the recommendations in the installation manual and that the power cables have been connected correctly.
- I have installed the batteries as specified in the installation manual.
- I have followed the Initial Start-Up of the UPS Using the Wizard – Only Applicable to Single UPSs with Internal Batteries, page 19.
- I have made all settings (including battery settings and life cycle monitoring) described in this manual.
- I have completed all functional tests successfully (normal mode, battery mode, and static bypass mode).
- I have successfully entered the UPS passcode provided by Schneider Electric.
- I confirm the installation has been completed and the UPS is running in normal mode and is powering the load.


Start Up a Single UPS in Normal Mode

NOTE: When the UPS starts, the stored settings will be used.


NOTE: The log can be accessed during start-up.

1. Check that all breakers are in the OFF (open) position.
2. Turn the static switch input breaker SSIB to the ON (closed) position.
The display turns on and the Home screen is shown.


3. Turn the unit output breaker UOB to the ON (closed) position.
Wait approximately 2030 seconds until the bypass and output LEDs turn green. The UPS starts up in static bypass mode.



4. Turn the unit input breaker UIB to the ON (closed) position.
The rectifier ramps up and the LEDs on the user interface show as follows:




5. When the UPS has initialized, the battery relay closes automatically.
The LEDs on the user interface show as follows:




- When the rectifier LED turns steady green, the inverter synchronizes with bypass.

The LEDs on the user interface show as follows:



- Wait approximately one minute until the inverter LED turns steady green, the UPS transfers automatically from static bypass mode to normal mode.


The LEDs on the user interface show as follows:



Transfer a Single UPS from Normal Mode to Static Bypass Mode

- On the display, select  and then select **Function > To bypass**.

The LEDs on the user interface show as follows:




Transfer a Single UPS from Static Bypass Mode to Normal Mode

NOTE: The UPS will normally transfer automatically from static bypass to normal mode. This procedure can be used to manually transfer to normal mode if the bypass frequency is above the specified limits.



1. On the display, select  and then select **ESC bypass**.

The LEDs on the user interface show as follows:




Transfer a Single UPS from Normal Mode to Maintenance Bypass Mode



1. On the display, select  and then select **Function > To bypass**.
2. Remove the cover from the maintenance bypass breaker MBB.
3. Turn the maintenance bypass breaker MBB to the ON (closed) position.
The load is now supplied via the maintenance bypass breaker.
4. Disconnect the battery relay from the display by selecting the battery symbol and selecting **Batt relay control ON/OFF** and confirm to turn off the battery relay. Verify that the **Relay status** is now off.
5. Open external battery breaker if external batteries are connected.
6. Turn the unit input breaker UIB to the OFF (open) position.
7. Turn the static switch input breaker SSIB to the OFF (open) position.
8. Turn the unit output breaker UOB to the OFF (open) position.

- Disconnect all batteries on the front of the UPS.



⚡ ⚠ DANGER

HAZARD OF ELECTRICAL SHOCK, EXPLOSION OR ARC FLASH

- Wait at least 5 minutes before removing the cover of the UPS after the display has turned off to allow for the capacitors to fully discharged.
- Always measure for hazardous voltages on all terminals before working on the UPS.

Failure to follow these instructions will result in death or serious injury.

Transfer a Single UPS from Maintenance Bypass Mode to Normal Mode

1. Check that all breakers except the maintenance bypass breaker MBB are in the OFF (open) position.
2. Reconnect the internal batteries of all UPSs and set all the battery breakers BB in the modular battery cabinets (if present) to the ON (closed) position.
3. Turn the static switch input breaker SSIB to the ON (closed) position.
The display turns on and the Home screen is shown.
4. Turn the unit output breaker UOB to the ON (closed) position.
The UPS starts up in static bypass mode.
5. Turn the maintenance bypass breaker MBB to the OFF (open) position and reinstall the cover in front of the breaker.




6. On the display select  and then select **Function > Clear alarm**.

NOTE: The system will not transfer to normal mode before the alarm has been cleared.

7. Turn the unit input breaker UIB to the ON (closed) position.
The rectifier ramps up. After UPS self-test, the battery relay closes automatically.
8. When the rectifier LED turns steady green, the inverter synchronizes with bypass.
9. Reinstall the cover on the maintenance bypass breaker MBB.

10. After approximately 60 seconds, the UPS will automatically transfer to normal mode.


The LEDs on the user interface show as follows:



Transfer a Parallel System from Normal Mode to Maintenance Bypass Mode

1. On all UPS displays, select  and then select **Function > To bypass**.
The parallel system will transfer to static bypass mode.
2. Turn the external maintenance bypass breaker Ext. MBB to the ON (closed) position.
The load is now supplied via the external maintenance bypass breaker.
3. Turn the battery breakers BB of all UPSs to the OFF (open) position.
4. Disconnect the battery relay from the display by selecting the battery symbol and selecting **Batt relay control ON/OFF** and confirm to turn off the battery relay. Verify that the **Relay status** is now off.
5. Open external battery breaker if external batteries are connected.
6. Turn the mains input breakers MIB and the bypass input breakers BIB of all UPSs to the OFF (open) position.
7. Turn the system isolation breaker SIB to OFF (open) position.

8. For the UPS with internal batteries, disconnect all batteries on the front of the UPS.



⚡⚠ DANGER

HAZARD OF ELECTRICAL SHOCK, EXPLOSION OR ARC FLASH

- Wait at least 5 minutes before removing the cover of the UPS after the display has turned off to allow for the capacitors to fully discharged.
- Always measure for hazardous voltages on all terminals before working on the UPS.

Failure to follow these instructions will result in death or serious injury.

Transfer a Parallel System from Maintenance Bypass Mode to Normal Mode

1. Check that:
 - all UPS breakers (unit input breaker UIB, static switch input breaker SSIB, and unit output breaker UOB) and the external unit output breaker Ext. UOB are in the ON (closed) position
 - the battery breakers BB are in the OFF (open) position
2. Reconnect the internal batteries of all UPSs and set all the battery breakers BB in the modular battery cabinets (if present) to the ON (closed) position.
3. Turn the system isolation breaker SIB to ON (closed) position.
4. Turn the bypass input breakers BIB of all UPSs to the ON (closed) position.
Wait approximately 2030 seconds until the bypass and the output LEDs turn green.
5. Turn the external maintenance bypass breaker Ext. MBB to the OFF (open) position.

NOTE: If the parallel system has dry contacts with Maint CB signal, select




and then select **Function > Clear alarm** on all UPS displays.

6. Turn the mains input breakers MIB of all UPSs to the ON (closed) position.
The rectifier ramps up. After UPS self-test, the battery relay closes automatically.
7. Close the external battery breaker if external batteries are part of the system.
8. When the rectifier LED turns steady green, the inverter synchronizes with bypass.
9. When the inverter LED turns steady green, the parallel system automatically transfers from static bypass to normal mode.

- Turn the battery breakers BB of all UPSs to the ON (closed) position.

The LEDs on the user interfaces show as follows:



The parallel system is now in normal mode.

Isolate a Single UPS from the Parallel System


Use this procedure to shut down one UPS in a running parallel system.

NOTE: Before initiating this procedure, ensure that the remaining UPS units can supply the load.



- On the display select  and then select confirm to power off the UPS.
- Turn the battery breaker(s) BB of the UPS to the OFF (open) position.
- Disconnect the battery relay from the display by selecting the battery symbol and selecting **Batt relay control ON/OFF** and confirm to turn off the battery relay. Verify that the **Relay status** is now off.
- Open external battery breaker if external batteries are connected.
- Turn the mains input breaker MIB of the UPS to the OFF (open) position.
- Turn the bypass input breaker BIB of the UPS to the OFF (open) position.
- Turn the external unit output breaker Ext. UOB of the UPS to the OFF (open) position.

- For the UPS with internal batteries, disconnect all batteries on the front of the UPS.



⚡⚠ DANGER

HAZARD OF ELECTRICAL SHOCK, EXPLOSION OR ARC FLASH

- Wait at least 5 minutes before removing the cover of the UPS after the display has turned off to allow for the capacitors to fully discharged.
- Always measure for hazardous voltages on all terminals before working on the UPS.

Failure to follow these instructions will result in death or serious injury.

Start Up and Add a UPS to a Running Parallel System

Use this procedure to start up a UPS and add it to a running parallel system.

IMPORTANT: Before a UPS can be added to a parallel system, the parallel system must be configured by Schneider Electric.


1. On the new UPS check that the UPS breakers (unit input breaker UIB, static switch input breaker SSIB, and unit output breaker UOB) are in the ON (closed) position.
2. Reconnect the internal batteries of all UPSs and set all ModBC BBs (if present) to the ON (closed) position.
3. Turn the external unit output breaker Ext. UOB of the UPS to the ON (closed) position.

- Turn the mains input breaker MIB and the bypass input breaker BIB of the UPS to the ON (closed) position.

The display turns on and the Home screen is shown.


When the UPS has initialized, the battery relay closes automatically. Close external battery breaker if external batteries are part of the system.

The LEDs on the user interface show as follows:




- When the rectifier LED turns steady green, the UPS starts the inverter.

The LEDs on the user interface show as follows:



- When the inverter LED turns steady green, the UPS automatically transfers to normal mode and joins the running parallel system.

The LEDs on the user interface show as follows:



- Verify correct load sharing between the parallel UPS units.

Start up the UPS from Cold Start

NOTICE

Cold start function is not a standard feature. If you want to have this feature, please contact SE for cold start kit (E3SOPT014) installation.

⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

All electrical work must be performed by qualified personnel. Practice Lockout/Tagout procedures. Do not wear jewelry when working with electrical equipment.

Failure to follow these instructions will result in death or serious injury.

⚠ WARNING

HAZARD FROM MOVING PARTS

Keep hands, clothing, and jewelry away from moving parts. Check the equipment for foreign objects before closing the doors and starting the equipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

1. After the cold start kit (E3SOPT014) is installed, wait for five minutes for the cold start capacitor to charge.
2. Check and make sure that all the MBBs, UIBs, SSIBs, and UOBs are in the OFF (open) position.
3. Turn on the UOB.
4. Press the cold start button for three seconds until the UPS starts up. The LED will light on the HMI.
5. If the startup wizard pops up, follow the UPS operation manual to complete the setup. When the setup is completed, the UPS will output in normal mode automatically.
6. If the startup wizard is disabled previously, the UPS will output in normal mode automatically.

Shut down the UPS from Cold Start



1. On the display, select  and then select confirm to power off the UPS.

Configuration

Register Your Easy UPS 3S

NOTE: The single Easy UPS 3S can also be registered using the mySchneider app which can be downloaded from App Store and Google Play.

1. When prompted for registration, go to www.schneider-electric.com/contactsupport to find your local service contact number.



2. On the display, select  and then select **Register**¹.
3. Call Schneider Electric and provide your four-digit activation code.
4. Type in the registration code provided by Schneider Electric.

Register	
Activation	XXXX
Registration code	<input type="text"/>
Register Later	

Set the Display Language



1. On the display, select  and then select **Language**.
2. Select your language from the list:

en: English	pt: Portuguese Brazilian
fr: French	es: European Spanish

¹ You can also select **Register Later** to postpone your registration

Set the Date and Time



1. On the display, select  and then select **Time**.
2. Set the date and time.

Set the UPS Settings

NOTICE

RISK OF EQUIPMENT DAMAGE

Only trained personnel following the required training course may undertake modifications to UPS system parameters.

Failure to follow these instructions can result in equipment damage.



1. On the display, select  and then select **Setting**.
2. Enter the password **3526**.

Back	←	Settings	⇒	Next
Enter password				
<input type="text" value="3526"/>				

3. Set the nominal input voltage (phase-neutral), the nominal output voltage (phase-neutral), and the nominal frequency.

NOTE: Nom input PN and Nom output PN must have the same voltage rating.

Back	←	Settings	⇒	Next
Nom input PN		XXX		
Nom output PN		XXX		
Nom freq		XX		

4. Restart the UPS to activate the settings.

Set the Battery Settings

NOTICE
<p>RISK OF EQUIPMENT DAMAGE</p> <ul style="list-style-type: none"> Only trained personnel following the required training course may undertake modifications to UPS system parameters. The battery parameters must set according to the actual installation before starting up the UPS. <p>Failure to follow these instructions can result in equipment damage.</p>



1. On the display, select and then select **Batt Settings**.
2. Enter the password **2334**.

Back Batt Settings Next
Enter password 2334

3. Set the battery settings:
 - a. **Batt number**: Verify the number of battery blocks is 20.
 - b. **Batt cap (AH)**: Set the battery capacity (battery block capacity (AH) x number of battery strings).
 - c. **Batt charge %**: Set the battery charge percentage (between 1% and 15%).

Back Batt Settings Next						
<table style="width: 100%; border: none;"> <tr> <td style="width: 60%;">Batt number</td> <td style="text-align: right;">20</td> </tr> <tr> <td>Batt cap (AH)</td> <td style="text-align: right;">XXX</td> </tr> <tr> <td>Batt charge %</td> <td style="text-align: right;">XX</td> </tr> </table>	Batt number	20	Batt cap (AH)	XXX	Batt charge %	XX
Batt number	20					
Batt cap (AH)	XXX					
Batt charge %	XX					

Recommended Battery Settings

NOTE: Settings with 9 Ah batteries (E3SFBTH2)

Number of battery strings ²	Batt number	Batt cap	Batt charge capacity %				
			10 kVA UPS	15 kVA UPS	20 kVA UPS	30 kVA UPS	40 kVA UPS
2	20	18	5	3	–	–	–
3	20	27	8	5	4	–	–
4	20	36	11	7	5	4	–
5	20	45	13	9	7	4	3
6	20	54	15	10	8	5	4
7	20	63	15	12	9	6	5
8	20	72	15	14	11	7	5
9	20	81	15	15	12	8	6
10	20	90	15	15	13	9	7
11	20	99	15	15	15	10	7
12	20	108	15	15	15	11	8
13	20	117	15	15	15	12	9
14	20	126	15	15	15	12	9
15	20	135	15	15	15	13	10
16	20	144	–	15	15	14	11
17	20	153	–	15	15	15	11
18	20	162	–	15	15	15	12
19	20	171	–	15	15	15	13
20	20	180	–	15	15	15	13
21	20	189	–	15	15	15	14
22	20	198	–	15	15	15	15
23	20	207	–	15	15	15	15
24	20	216	–	15	15	15	15
25	20	225	–	15	15	15	15
26	20	234	–	15	15	15	15
27	20	243	–	15	15	15	15
28	20	252	–	–	–	15	15
29	20	261	–	–	–	15	15
30	20	270	–	–	–	15	15
31	20	279	–	–	–	15	15
32	20	288	–	–	–	15	15
33	20	297	–	–	–	15	15
34	20	306	–	–	–	15	15
35	20	315	–	–	–	15	15
36	20	324	–	–	–	15	15
37	20	333	–	–	–	15	15
38	20	342	–	–	–	15	15
39	20	351	–	–	–	15	15
40	20	360	–	–	–	15	15
41	20	369	–	–	–	15	15
42	20	378	–	–	–	15	15
43	20	387	–	–	–	–	15
44	20	396	–	–	–	–	15

2. Total number of battery strings in UPS and modular battery cabinet.

Number of battery strings ³	Batt number	Batt cap	Batt charge capacity %				
			10 kVA UPS	15 kVA UPS	20 kVA UPS	30 kVA UPS	40 kVA UPS
45	20	405	–	–	–	–	15
46	20	414	–	–	–	–	15
47	20	423	–	–	–	–	15
48	20	432	–	–	–	–	15
49	20	441	–	–	–	–	15
50	20	450	–	–	–	–	15
51	20	459	–	–	–	–	15
52	20	468	–	–	–	–	15
53	20	477	–	–	–	–	15
54	20	486	–	–	–	–	15


3. Total number of battery strings in UPS and modular battery cabinet.

Set the Life Cycle Monitoring

NOTICE
<p>RISK OF EQUIPMENT DAMAGE</p> <p>Only trained personnel following the required training course may undertake modifications to UPS system parameters.</p> <p>Failure to follow these instructions can result in equipment damage.</p>



1. On the display, select and then select **LCM Set**.
2. You now have the following options:



- Select **Set dust filter expiration** to set the service life of the dust filter.

Settings

Setting	Default Value	Available Settings
LCD contrast	60	0 to 100
Date and Time	05/07/2013 08:55:55	Year > 2000
Language	English	English, Spanish, Portuguese Brazilian, and French
Input voltage (LN)	120 V	120 V/127 V
Input frequency	60 Hz	50 Hz/60 Hz
Output voltage (LN)	120 V	120 V/127 V
Output frequency	60 Hz	50 Hz/60 Hz
EPO transfer to bypass	Enable	Disable
Auto boost	Disable	Enable
Auto maint	Disable	Enable
System mode	single	parallel/ECO/parallel ECO/self aging
United number	1	1 to 4
System ID	0	0 to 3
Adjusted output voltage	120	Output voltage ±5 V
Frequency slew rate	2 Hz/s	0.1 to 3.0 Hz/s
Frequency synchronization window	3 Hz	0.5 to 5.0 Hz
Monochrome LCD time (min)	10	1/3/5/10/20/30
Bypass voltage upper limit (%)	20	10/20/25

Setting	Default Value	Available Settings
Bypass voltage lower limit (%)	-20	-10/-15/-30/-40
Bypass frequency limited (Hz)	±5	±1/±3/±5
System restart mode after end of discharge	Normal	Normal/Bypass only/No output
Fan maintenance period	34560 hours (48 months)	0 to 60000 hours
DC capacitor maintenance period	34560 hours (48 months)	0 to 60000 hours
Warranty period	9 months	1 to 36 months
AC capacitor maintenance period	120 months	60 to 120 months
APS maintenance period	84 months	36 to 120 months
Dust filter maintenance period	12 months	0/3/4/5/12 months
Battery maintenance reminding period	1440 days (48 months)	100 to 300 days
Battery number	20	20
Battery AH	9	1 to 30000
Float charge voltage/cell (V)	2.25	2.10 to 2.35
Boost charge voltage/cell (V)	2.25	2.20 to 2.45
End of discharge voltage/cell, at 3 C current (V)	1.6	1.60 to 1.85
End of discharge voltage/cell, at 0.05 C current (V)	1.75	1.65 to 1.90
Charge current percent limit (%)	10	1 to 15
Battery temperature compensation	0	0 to 5 mV/°C
Boost charge time limit	12 hours	1 to 48 hours
Auto boost period	2160 hours (3 months)	720 to 30000 hours, available when auto boost is enabled
Auto maintenance discharge period	6480 hours (9 months)	720 to 30000 hours, available when auto maintenance is enabled

Tests

Perform a Battery Maintenance Test

NOTICE

RISK OF EQUIPMENT DAMAGE

Do not perform a battery maintenance test without load connected.

Failure to follow these instructions can result in equipment damage.

Prerequisite:

- The bypass supply must be within specifications.
- The battery capacity must be above 25%.

The battery maintenance test is used to test the condition of the batteries.

During the battery maintenance test, the system transfers to battery mode and discharges the batteries until the battery low voltage alarm is reached.



1. On the display, select  and then select **Maint test**.

NOTE: If you wish to manually stop the battery test, select **Stop test**.

If the battery maintenance test is passed, **Battery maintenance OK** will be recorded in the log. If the battery maintenance test is not passed, **Batt maint incomplete** will be recorded in the log.

Perform a Battery Test

The purpose of the battery test is to verify the connection of the batteries and to check the battery capacity.

Prerequisite:

- The bypass supply must be within specifications.
- The battery capacity must be above 25%.
- The battery voltage must be above 95% of the float voltage.

During the battery test, the system transfers to battery mode for approximately 30 seconds and then returns to normal mode.



1. On the display, select  and then select **Battery test**.

Maintenance

Parts Replacement

Determine if you need a Replacement Part


To determine if you need a replacement part, contact Schneider Electric and follow the procedure below so that the representative can assist you promptly:

1. In the event of an alarm condition, scroll through the alarm lists, record the information, and provide it to the representative.
2. Write down the serial number of the unit so that you will have it easily accessible when you contact Schneider Electric.
3. If possible, call Schneider Electric from a telephone that is within reach of the display so that you can gather and report additional information to the representative.
4. Be prepared to provide a detailed description of the problem. A representative will help you solve the problem over the telephone, if possible, or will assign a return material authorization (RMA) number to you. If a module is returned to Schneider Electric, this RMA number must be clearly printed on the outside of the package.
5. If the unit is within the warranty period and has been started up by Schneider Electric, repairs or replacements will be performed free of charge. If it is not within the warranty period, there will be a charge.
6. If the unit is covered by a Schneider Electric service contract, have the contract available to provide information to the representative.


Replace the Dust Filter

1. Open the door.

2. Loosen the screws and remove the metal brackets and the manual box.



3. Replace the dust filter.



4. Reinstall the metal brackets and fasten with the screws.
5. Close the door.
6. Reset the dust filter counter in the display. See [Set the Life Cycle Monitoring](#), page 36 for more information.

Troubleshooting

View the Active Alarms

1. On the display select .
See [Status and Alarm Messages](#), page 41 for a list of alarm messages and corrective actions.
2. Use  and  to go through the list of active alarms.

Buzzer

NOTE: The buzzer turns on as soon as an alarm condition is detected. The buzzer makes two short beeps and a long beep for general system alarms. The buzzer makes a continuous beep for critical alarms. It can be turned off by

selecting  on the home screen.

Status and Alarm Messages

This section lists status and alarm messages from the display. The display messages are listed in alphabetical order, and a suggested corrective action is listed with the display alarm message to help you troubleshoot problems.

Display text	Description	Corrective action
Battery boost charging	The batteries are charged with the configured boost charge voltage.	
Battery connected	The batteries are connected.	
Battery discharging	The load is drawing more power than the UPS can draw from the input, causing the UPS to draw power from the batteries.	Reduce the load. Please contact Schneider Electric.
Battery disconnected	The batteries are not connected.	Connect the batteries.
Battery expired	The battery service life has expired.	Replace the battery.
Battery end of discharge	The battery capacity is below the minimum acceptable value.	Recharge the batteries.
Battery float charging	The batteries are charged with the configured float charge voltage.	
Battery log reset	Reset the battery log.	
Batt maint incomplete	The battery maintenance test was not passed.	
Battery maintenance	Start the battery maintenance test.	
Battery maintenance OK	The battery maintenance test has been successfully completed.	
Battery temperature high	The battery temperature is too high.	Check the battery temperature.

Display text	Description	Corrective action
Battery test	Start the battery test.	
Battery test incomplete	The battery test was not passed.	
Battery test OK	The battery test has been successfully completed.	
Battery voltage low	Low voltage on battery.	Check the battery.
Battery wiring incorrect	The battery wiring is incorrect.	Check the battery wiring. Please contact Schneider Electric.
Battery/charger inoperable	The battery or charger is inoperable.	Check the battery. Check the charger. Please contact Schneider Electric.
Byp freq exceeds limits	The bypass frequency exceeds the limit.	Check the status of the bypass source. Please contact Schneider Electric.
Bypass fan inoperable	The UPS has one or more inoperable fans.	Check the fans.
Bypass fan time reset	Reset the service life timer for the fan.	
Bypass out of tolerance	The bypass voltage is out of tolerance.	Check the status of the bypass source. Please contact Schneider Electric.
Bypass overload	The load is drawing more power than the bypass source can supply.	Reduce the load. Please contact Schneider Electric.
Bypass overload timeout	The UPS can no longer sustain a Bypass overload situation.	Reduce the load. Please contact Schneider Electric.
Bypass sequence incorrect	The phase rotation on bypass is incorrect.	Check the status of the bypass source. Please contact Schneider Electric.
Bypass unavailable	The bypass source is not available.	Check the status of the bypass source. Please contact Schneider Electric.
Capacitor expired	Capacitor service life has expired.	Replace the capacitor.
Capacitor time reset	Capacitor service life timer has been reset.	
Clear log	Clear the log.	
DC bus overvoltage	Overvoltage on the DC bus.	
Dust filter expired	The dust filter service life has expired.	Replace the Dust Filter, page 39.
EPO	An EPO (emergency power off) device is activated.	Deactivate the EPO (emergency power off) device.
Fan expired	Fan service life has expired.	Replace the fan.
Fan inoperable	The UPS has one or more inoperable fans.	Check the fans. Please contact Schneider Electric.
Fan time reset	The fan service life timer has been reset.	
Firmware incompatible	The firmware is detected as incompatible with the rest of the system.	Perform a firmware update.
Generator input	Generator is supplying the UPS.	

Display text	Description	Corrective action
Inhibit transfer to inv.	Inhibit transfer to inverter operation.	
Inlet temperature high	Air inlet temperature is too high.	Check the status of the air inlet. Reduce the room temperature.
Inlet/outlet temp	Air inlet and outlet temperature.	
Input current unbalanced	Input current is unbalanced.	Check the status of the input source. Please contact Schneider Electric.
Input neutral unavailable	Input neutral is not available.	Check the status of the input neutral. Please contact Schneider Electric.
Input out of tolerance	The input voltage is out of tolerance.	Check the status of the input source. Please contact Schneider Electric.
Input overcurrent timeout	The UPS can no longer sustain an Input overcurrent situation.	Check the status of the input source. Please contact Schneider Electric.
Input SCR fan inoperable	Input SCR fan is inoperable.	Check the status of the input SCR fan. Please contact Schneider Electric.
Input SCR temp high	Input SCR temperature is too high.	Check the status of the input SCR fan. Please contact Schneider Electric.
Inverter high temp	Inverter temperature is too high.	Check the status of the inverter. Please contact Schneider Electric.
Inverter IGBT inoperable	The inverter IGBT is inoperable.	Check the status of the inverter IGBT. Please contact Schneider Electric.
Inverter inoperable	The inverter is inoperable.	Check the status of the inverter. Please contact Schneider Electric.
Inverter overload timeout	The UPS can no longer sustain an Inverter overload situation.	Check the status of the inverter. Please contact Schneider Electric.
Inverter shutdown	The inverter is shutting down.	
Inv DATA CAN incorrect	Inverter DATA CAN is incorrect.	
Inv firmware upgrade	The inverter firmware has been upgraded.	
Inv IO CAN incorrect	Inverter IO CAN is incorrect.	
Load on bypass	The UPS is in static bypass mode and the load is supplied by the bypass source.	
Load disconnected	The load has been disconnected or the unit output breaker UOB is open.	Check the load. Close the unit output breaker UOB.
Load on inverter	The UPS is in inverter operation mode and the load is supplied by the UPS.	
Low battery shutdown	The UPS is shutting down due to battery end of discharge	Recharge the batteries and restart the UPS. If auto-restart mode is configured, the UPS will start automatically restart when the mains return.
Man. transfer to inverter	Manual transfer to inverter operation.	

Display text	Description	Corrective action
Manual shutdown	Manual shutdown.	
MBB closed	The maintenance bypass breaker MBB is closed, supplying the load with unprotected power from the bypass source.	
MBB open	The maintenance bypass breaker is open.	
Module ID duplicate	The module ID has a duplicate. The module ID must be unique.	Check the ID of the modules.
No inlet temp sensor	No inlet temperature sensor present.	Check the status of the inlet temperature sensor.
No input temp sensor	No input temperature sensor present.	Check the status of the input temperature sensor.
No outlet temp sensor	No outlet temperature sensor present.	Check the status of the outlet temperature sensor.
Nom power out of tolerance	The nominal power does not match the UPS hardware.	Check the status of the input source. Please contact Schneider Electric.
Outlet temperature high	Air outlet temperature is too high.	Check the status of the air outlet. Please contact Schneider Electric.
Output short circuit	A short circuit is present on the output.	Check the status of the output. Please contact Schneider Electric.
Output overload	The load is drawing more power than the UPS system can supply.	Reduce the load. Contact Schneider Electric.
Parallel cabling incorrect	The parallel cabling is incorrect.	Check the status of the parallel cables. Please contact Schneider Electric.
Power sharing incorrect	The power sharing between the UPS units is incorrect.	Please check the load sharing on the UPS units. Redistribute the load between UPS units. Please contact Schneider Electric.
PWM sync unavailable	The PWM synchronization is unavailable.	Check the status of the PWM sync. Please contact Schneider Electric.
Rec firmware upgrade	The rectifier firmware has been upgraded.	
Rec soft start unavailable	The rectifier soft start is unavailable.	Check the status of the rectifier. Please contact Schneider Electric.
Rectifier high temp	The rectifier temperature is too high.	Check the status of the rectifier. Please contact Schneider Electric.
Rectifier inoperable	The rectifier is inoperable.	Check the status of the rectifier. Please contact Schneider Electric.
Relay disconnected	A relay is disconnected.	Check the status of the relays. Please contact Schneider Electric.
Relay short-circuit	A relay has short-circuited.	Check the status of the relays. Please contact Schneider Electric.
Room temp high	The room temperature is high.	Reduce the room temperature.
Save settings	Settings have been changed.	
Shutdown	UPS shutdown.	
Signal cable disconnect	Signal cable is disconnected.	Check the signal cable.

Display text	Description	Corrective action
Sync pulse unavailable	Sync pulse is unavailable. The UPS is not able to synchronize.	Check the sync pulse. Please contact Schneider Electric.
System overload	The load is drawing more power than the UPS system can supply.	Reduce the load. Contact Schneider Electric.
System setting incorrect	The system settings are incorrect.	Check the system settings. Contact Schneider Electric.
Technical check recommended	A technical check is recommended.	Contact Schneider Electric.
Transfer to bypass	Transfer the UPS to static bypass mode.	
Transfer to inverter	Transfer the UPS to inverter operation.	
Transfers exceed limits	There have been too many transfers between operation modes in a given time period.	Contact Schneider Electric.
Warranty expiring soon	Warranty is expiring soon.	Contact Schneider Electric.

View the Logs



1. On the display, select  to select a log messages with the time mark.
2. Use  and  to go through the list of logs.

Up	←	Log	⇒	Down
		Input out of tolerance		Ⓒ
		007 2021-05-27 13:17:40		
		Load on bypass		Ⓔ
		008 2021-05-27 13:17:29		

NOTE: C means an event is cleared or disappears, and S means an event is set or occurs.

Schneider Electric
35 rue Joseph Monier
92500 Rueil Malmaison
France

+ 33 (0) 1 41 29 70 00



As standards, specifications, and design change from time to time,
please ask for confirmation of the information given in this publication.

© 2020 – 2023 Schneider Electric. All rights reserved.

990-6409B-001