Galaxy Lithium-ion Battery Cabinet

With 10, 13, 16, or 17 Battery Modules

Installation and Operation

LIBSESMG10IEC, LIBSESMG13IEC, LIBSESMG16IEC, LIBSESMG17IEC LIBSESMG10UL, LIBSESMG13UL, LIBSESMG16UL, LIBSESMG17UL

Latest updates are available on the Schneider Electric website 12/2024





Legal Information

The information provided in this document contains general descriptions, technical characteristics and/or recommendations related to products/solutions.

This document is not intended as a substitute for a detailed study or operational and site-specific development or schematic plan. It is not to be used for determining suitability or reliability of the products/solutions for specific user applications. It is the duty of any such user to perform or have any professional expert of its choice (integrator, specifier or the like) perform the appropriate and comprehensive risk analysis, evaluation and testing of the products/solutions with respect to the relevant specific application or use thereof.

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this document are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owner.

This document and its content are protected under applicable copyright laws and provided for informative use only. No part of this document may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the document or its content, except for a non-exclusive and personal license to consult it on an "as is" basis.

Schneider Electric reserves the right to make changes or updates with respect to or in the content of this document or the format thereof, at any time without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this document, as well as any non-intended use or misuse of the content thereof.



Find the manuals here: Trouvez les manuels ici: 在这里找到手册 Hier finden Sie die Handbücher: Encuentre los manuales aquí: Encontre os manuais aqui:



Table of Contents

| Important Safety Instructions — SAVE THESE | |
|---|----|
| INSTRUCTIONS | 7 |
| FCC Statement | 8 |
| Electromagnetic Compatibility | 8 |
| Safety Precautions | 8 |
| Electrical Safety | 11 |
| Battery Safety | 11 |
| Specifications | 13 |
| Recommended Cable Sizes | 13 |
| Recommended Cable Lugs | 14 |
| Torque Specifications | 14 |
| Galaxy Lithium-ion Battery Cabinet Weights and Dimensions | 14 |
| Clearance | 15 |
| Environment | 15 |
| Overview of Accessory Kits | 16 |
| Installation Procedure | 18 |
| Prepare for Installation | |
| Install the Rear Seismic Anchoring | |
| Position and Interconnect the Battery Cabinets | |
| Install the Front Seismic Anchoring | |
| Install the Battery Modules in the Battery Cabinet | |
| Connect the Power Cables | |
| Overview of Communication Interface | 32 |
| Route the Signal Cables to the Switchgear, Rack BMS, and System BMS | |
| Ports | 33 |
| Overview of Signal Cables between the Battery Cabinets and the | |
| Auxiliary Contacts in the UPS | 37 |
| Overview of Signal Cables for Alarms and Battery Breaker Trip | 39 |
| Overview of CAN Bus Cables between the Battery Cabinets | 40 |
| Overview of EPO Signal Cables | 40 |
| Operation Procedures | 41 |
| Shut Down the Battery Solution | 41 |
| Restart the Battery Solution | 41 |
| Monitor the Battery System | 42 |
| Download Data Log from the Data Log Kit (Optional) | 42 |
| Troubleshooting | 44 |
| Status LEDs | 44 |
| PSU LEDs | 45 |
| Data Log Kit LEDs | 46 |
| Alarm List | 48 |
| Protection Protocols | 48 |
| Decommission or Move the Battery Cabinet to a New | |
| Location | 56 |
| | _ |

Important Safety Instructions — SAVE THESE INSTRUCTIONS

Read these instructions carefully and look at the equipment to become familiar with it before trying to install, operate, service or maintain it. The following safety messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a "Danger" or "Warning" safety message indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages with this symbol to avoid possible injury or death.

ADANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

Failure to follow these instructions will result in death or serious injury.

AWARNING

WARNING indicates a hazardous situation which, if not avoided, **could result** in death or serious injury.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

ACAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

Failure to follow these instructions can result in injury or equipment damage.

NOTICE

NOTICE is used to address practices not related to physical injury. The safety alert symbol shall not be used with this type of safety message.

Failure to follow these instructions can result in equipment damage.

Please Note

Electrical equipment should only be installed, operated, serviced, and maintained by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

Per IEC 62040-1: "Uninterruptible power systems (UPS) -- Part 1: Safety Requirements," this equipment, including battery access, must be inspected, installed and maintained by a skilled person.

The skilled person is a person with relevant education and experience to enable him or her to perceive risks and to avoid hazards which the equipment can create (reference IEC 62040-1, section 3.102).

FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Electromagnetic Compatibility

NOTICE

RISK OF ELECTROMAGNETIC DISTURBANCE

This is a product category C2 UPS product. In a residential environment, this product may cause radio inference, in which case the user may be required to take additional measures.

Failure to follow these instructions can result in equipment damage.

Safety Precautions

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Read all instructions in the installation manual before installing or working on this product.

Failure to follow these instructions will result in death or serious injury.

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Do not install the product until all construction work has been completed and the installation room has been cleaned.
- Build a clear, permanent, restricted access area around the system.

Failure to follow these instructions will result in death or serious injury.

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

The product must be installed according to the specifications and requirements as defined by Schneider Electric. It concerns in particular the external and internal protections (upstream breakers, battery breakers, cabling, etc.) and environmental requirements. No responsibility is assumed by Schneider Electric if these requirements are not respected.

Failure to follow these instructions will result in death or serious injury.

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

The UPS system must be installed according to local and national regulations. Install the UPS according to:

- IEC 60364 (including 60364–4–41- protection against electric shock, 60364–4–42 protection against thermal effect, and 60364–4–43 protection against overcurrent), or
- NEC NFPA 70, or
- · Canadian Electrical Code (C22.1, Part 1)

depending on which one of the standards apply in your local area.

Failure to follow these instructions will result in death or serious injury.

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Install the product in a temperature controlled indoor environment free of conductive contaminants and humidity.
- Install the product on a non-flammable, level and solid surface (e.g. concrete) that can support the weight of the system.

Failure to follow these instructions will result in death or serious injury.

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

The product is not designed for and must therefore not be installed in the following unusual operating environments:

- · Damaging fumes
- Explosive mixtures of dust or gases, corrosive gases, or conductive or radiant heat from other sources
- Moisture, abrasive dust, steam or in an excessively damp environment
- Fungus, insects, vermin
- Salt-laden air or contaminated cooling refrigerant
- Pollution degree higher than 2 according to IEC 60664-1
- · Exposure to abnormal vibrations, shocks, and tilting
- · Exposure to direct sunlight, heat sources, or strong electromagnetic fields

Failure to follow these instructions will result in death or serious injury.

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Do not drill or cut holes for cables or conduits with the gland plates installed and do not drill or cut holes in close proximity to the product.

Failure to follow these instructions will result in death or serious injury.

AAWARNING

HAZARD OF ARC FLASH

Do not make mechanical changes to the product (including removal of cabinet parts or drilling/cutting of holes) that are not described in the installation manual.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

AWARNING

CHEMICAL HAZARD

This product can expose you to chemicals including Tetrabromobisphenol A, which is known to the State of California to cause cancer. For more information, go to www.P65Warnings.ca.gov

Failure to follow these instructions can result in death, serious injury, or equipment damage.

NOTICE

RISK OF OVERHEATING

Respect the space requirements around the product and do not cover the ventilation openings when the product is in operation.

Failure to follow these instructions can result in equipment damage.

Electrical Safety

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Electrical equipment must be installed, operated, serviced, and maintained only by qualified personnel.
- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices.
- Turn off all power supplying the UPS system before working on or inside the equipment.
- Before working on the UPS system, check for hazardous voltage between all terminals including the protective earth.
- The battery cabinet contains an internal energy source. Hazardous voltage
 can be present even when the UPS system is disconnected from the utility/
 mains supply. Before installing or servicing the UPS system, ensure that the
 units are OFF and that utility/mains and batteries are disconnected.
- A disconnection device (e.g. disconnection circuit breaker or switch) must be installed to enable isolation of the system from upstream power sources in accordance with local regulations. This disconnection device must be easily accessible and visible.
- The battery cabinet must be properly earthed/grounded and due to a high leakage current, the earthing/grounding conductor must be connected first.

Failure to follow these instructions will result in death or serious injury.

Battery Safety

AA DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Battery circuit breakers must be installed according to the specifications and requirements as defined by Schneider Electric.
- Servicing of batteries must only be performed or supervised by qualified personnel knowledgeable of batteries and the required precautions. Keep unqualified personnel away from batteries.
- Disconnect charging source prior to connecting or disconnecting battery terminals.
- Do not dispose of batteries in a fire as they can explode.
- Do not open, alter, or mutilate batteries.

Failure to follow these instructions will result in death or serious injury.

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Batteries can present a risk of electric shock and high short-circuit current. The following precautions must be observed when working on batteries

- Remove watches, rings, or other metal objects.
- Use tools with insulated handles.
- · Wear protective glasses, gloves and boots.
- Do not lay tools or metal parts on top of batteries.
- Disconnect the charging source prior to connecting or disconnecting battery terminals.
- Determine if the battery is inadvertently grounded. If inadvertently grounded, remove source from ground. Contact with any part of a grounded battery can result in electric shock. The likelihood of such shock can be reduced if such grounds are removed during installation and maintenance (applicable to equipment and remote battery supplies not having a grounded supply circuit).

Failure to follow these instructions will result in death or serious injury.

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

When replacing batteries, always replace with the same battery module type.

Failure to follow these instructions will result in death or serious injury.

NOTICE

RISK OF EQUIPMENT DAMAGE

- Lithium-ion batteries should not be stored beyond 15 months from the date
 of production. If they are stored for longer the calendar degradation will
 cause the batteries to be irreversible degraded beyond what is expected a
 reduced runtime will be the consequence. Performance guarantee will be
 measured from the time of deployment or from production date +15 months,
 whichever comes first. For storage beyond 15 months, contact Schneider
 Electric
- If the UPS system remains de-energized for a long period, Schneider Electric recommends to shut down the battery cabinet completely.

Failure to follow these instructions can result in equipment damage.

Specifications

| Commercial reference | LIBSESMG10IEC/ LIBSESMG10UL | LIBSESMG13IEC/ LIBSESMG13UL | LIBSESMG16IEC/ LIBSESMG16UL | LIBSESMG17IEC/ LIBSESMG17UL |
|---|--------------------------------|--------------------------------|--------------------------------|--------------------------------|
| Nominal battery voltage (VDC) at 3.8 V per cell | 304 | 395 | 486 | 517 |
| Charge current default rate (CA rate) | 0.7 | 0.7 | 0.7 | 0.7 |
| Maximum continuous charge current rate (CA rate) | 1.0 | 1.0 | 1.0 | 1.0 |
| Float charge voltage (VDC) at 4.2 V per cell | 336 | 436 | 537 | 571 |
| End of discharge voltage (VDC) at 3.0 V per cell | 240 | 312 | 384 | 408 |
| Maximum continuous 100% depth of discharge power (kW) | 108 | 140 | 173 | 184 |
| Maximum partial depth of discharge power (kW) | 135 | 176 | 218 | 231 |
| Short circuit rating value (kA) - Isc, RMS (Isc, MAX) | 2.9 (9.0) | 2.9 (9.0) | 2.9 (9.0) | 2.9 (9.0) |

NOTE: The battery temperature must return to ± 3 °C / ± 5 °F of the room temperature before a new discharge at maximum continuous discharge power. If not, the battery breaker may be tripped due to overtemperature protection.

NOTE: The working temperature for the busbars should be no more than 100 $^{\circ}$ C.

Recommended Cable Sizes

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

All wiring must comply with all applicable national and/or electrical codes. The maximum allowable cable size is 185 mm² (IEC) / 350 kcmil (UL).

Failure to follow these instructions will result in death or serious injury.

NOTE: Refer to the UPS installation manual for recommended cable sizes.

Recommended Cable Lugs

Copper - One Hole Cable Lug

| Cable size | Bolt size | Cable lug type | Crimp tool | Die |
|------------|-----------|----------------|------------|---------------------|
| 3/0 AWG | M10x30 | LCA3/0-12-X | CT-720 | CD-720-2 Orange P50 |
| 4/0 AWG | M10x30 | LCA4/0-12-X | CT-720 | CD-720-3 Purple P54 |
| 300 kcmil | M10x30 | LCA300-12-X | CT-720 | CD-720-4 White P66 |
| 350 kcmil | M10x30 | LCA350-12-X | CT-720 | CD-720-5 Red P71 |

Copper - Two Hole Cable Lug

| Cable size | Bolt size | Cable lug type | Crimp tool | Die |
|------------|-----------|----------------|------------|-----------------------|
| 3/0 AWG | M10x30 | LCC3/0-12D-X | CT-930 | CD-920-3/0 Orange P50 |
| 4/0 AWG | M10x30 | LCC4/0-12D-X | CT-930 | CD-920-4/0 Purple P54 |
| 300 kcmil | M10x30 | LCC300-12-X | CT-930 | CD-920-300 White P66 |
| 350 kcmil | M10x30 | LCC350-12-X | CT-930 | CD-920-350 Red P71 |

Torque Specifications


| Bolt size | Torque |
|-----------|---------------------|
| M4 | 1.7 Nm (1.25 lb-ft) |
| M6 | 5 Nm (3.69 lb-ft) |
| M8 | 14 Nm (10.33 lb-ft) |
| M10 | 30 Nm (22.13 lb-ft) |
| M12 | 46 Nm (33.93 lb-ft) |

Galaxy Lithium-ion Battery Cabinet Weights and Dimensions

| Commercial reference | Weight kg (lbs) | Height mm (in) | Width mm (in) | Depth mm (in) |
|----------------------|-----------------|----------------|---------------|---------------|
| LIBSESMG10IEC | 355 (782) | 1970 (77.56) | 650 (25.59) | 587 (23.11) |
| LIBSESMG10UL | 355 (782) | 1970 (77.56) | 650 (25.59) | 587 (23.11) |
| LIBSESMG13IEC | 415 (915) | 1970 (77.56) | 650 (25.59) | 587 (23.11) |
| LIBSESMG13UL | 415 (915) | 1970 (77.56) | 650 (25.59) | 587 (23.11) |
| LIBSESMG16IEC | 470 (1036) | 1970 (77.56) | 650 (25.59) | 587 (23.11) |
| LIBSESMG16UL | 470 (1036) | 1970 (77.56) | 650 (25.59) | 587 (23.11) |
| LIBSESMG17IEC | 490 (1080) | 1970 (77.56) | 650 (25.59) | 587 (23.11) |
| LIBSESMG17UL | 490 (1080) | 1970 (77.56) | 650 (25.59) | 587 (23.11) |

Clearance

NOTE: Clearance dimensions are published for airflow and service access only. Consult with the local safety codes and standards for additional requirements in your local area.



^{*} For system with seismic anchoring.

Environment

| | Operating | Storage |
|-------------------|--|---|
| Temperature | Recommended operating temperature: 18 °C to 28 °C (64 °F to 82 °F) | Battery modules with the original packing materials: 5 °C to 28 °C (41 °F to 82 °F) Battery cabinet with original packing materials: 5 °C to 40 °C (41 °F to 104 °F) (non-freezing) Temperature uniformity should be within 5 °C (41 °F) during storage period. |
| Relative humidity | 0-80% Non-condensing | Battery modules with the original packing materials: 0-90% Non-condensing Battery cabinet with the original packing materials: 0-80% Non-condensing |
| Elevation | 0-2000 m(0-6562 ft) | |
| Protection class | IP20 | |
| Color | RAL 9003, gloss level 85% | |

Overview of Accessory Kits

Accessory Kit 0M-95318: Busbar Kit

NOTE: Save this accessory kit for the field service representative. The busbars will be installed by Schneider Electric during the start-up service.

Accessory Kit 0M-95319: Cover Kit

NOTE: Save this accessory kit for the field service representative. The covers will be installed by Schneider Electric during the start-up service.

Accessory Kit 0M-95320: Cable Kit

| Part Number | Description | Quantity | Used in |
|--|---|----------|---|
| 0W76926 | 76926 Signal cable from battery module to battery module – standard | | Note: Save these signal cables for the field service representative. These signal cables will be installed by |
| 0W76936 | Signal cable from battery module to battery module – long | 1 | Schneider Electric during the start-up service. |
| 0W76933 | Signal cable from battery module to RBMS | 1 | |
| 0W76928 Signal cable from RBMS CAN 2 to RBMS CAN 1 in next battery cabinet | | 1 | Route the Signal Cables to the Switchgear, Rack BMS, and System BMS Ports, page 33 |
| 0W76929 | Signal cable from MCCB AUX 1 to UPS 1 | | |
| 0W76934 | Signal cable from MCCB AUX 2 to MCCB AUX 1 in next battery cabinet | | |
| 0W13444 | Signal cable from SGB I/O 1 to the UPS | | _ |
| 0W13442 | Signal cable from SGB I/O 2 to the UPS | 1 | |
| 0W76972 | Signal cable from SGB I/O 1 to SGB I/O 1 between the battery cabinets | 1 | |

Accessory Kit 0M-95331: Seismic Anchoring and Fuse Kit

| Part Number | Description | Quantity | Used in |
|-----------------------------------|--|----------|--|
| 870-50102 | Anchor parts | 4 | Install the Rear Seismic Anchoring, page 21 |
| 870-51172 | Interconnection plate between seismic brackets | • | |
| 803-0684 | M6 x 12 torx screw with washer | 4 | |
| 803-0686 | M6 x 16 torx with washer | 18 | Install the Rear Seismic Anchoring, page 21 and Position and Interconnect the Battery Cabinets, page 23. |
| TME00409 500 A fast acting fuse 1 | | 1 | Note: Save for the field service representative. The fuses will be |
| TME24508 | M12 x 35 stud | 2 | installed by Schneider Electric during the start-up service. |
| HUA26611 | M12 hexagonal nut with spring washer | 2 | · |

| Part Number | Description | Quantity | Used in |
|-------------|----------------|----------|---------|
| HUA41574 | 3 A rated fuse | 2 | |

Optional Kit

| Part Number | Description | Quantity | Used in |
|------------------------------|---|----------|--|
| LIBSEOPT002 | Galaxy LIB cabinet SMPS AC/DC converter | 11 | Note: Scan the QR code on the SMPS AC/DC converter to find the installation manual. |
| LIBSEFUSEKIT | Galaxy 10-module LIB cabinet fuse kit | 1 | Note: Save for the field service representative. The busbars will be installed by Schneider Electric during the start-up service. |
| LIBSEDATABMSIEC ² | Galaxy LIB cabinet data log kit IEC version | 1 | Note: Save for the field service representative. |
| LIBSEDATABMSUL ² | Galaxy LIB cabinet data log kit UL version | 1 | Note: Save for the field service representative. |
| LIBSEOPT001 | Galaxy LIB 25 m communication cable kit | 1 | |

One AC/DC converter box can supply up to 10 battery cabinets. For 11+ battery cabinets, at least two AC/DC converter boxes are required.


^{2.} Install one data log kit for each battery system.

Installation Procedure


- 1. Prepare for Installation, page 19.
- 2. Install the Rear Seismic Anchoring, page 21.
- 3. Position and Interconnect the Battery Cabinets, page 23.
- 4. Install the Front Seismic Anchoring, page 25.
- 5. Install the Battery Modules in the Battery Cabinet, page 26.
- 6. Connect the Power Cables, page 28.
- 7. Route the Signal Cables to the Switchgear, Rack BMS, and System BMS Ports, page 33.

Prepare for Installation


1. Remove the indicated cover.




2. Remove the two transparent covers.



3. Remove the plate in front of the battery shelves.




4. Remove the four boxes with accessory kits from the bottom of the cabinet. Refer to Overview of Accessory Kits, page 16 for more information on the accessory kits.



Install the Rear Seismic Anchoring


1. Mount the rear seismic assembly (4 x 870-50102 and M6 x 16 torx screws from accessory kit 0M-95331 and the rear shipping bracket) to the floor. Use appropriate hardware for the floor type – the hole diameter in the rear seismic bracket is ø14 mm. The minimum requirement is M12 strength grade 8.8 hardware.

Rear View




2. In systems with more battery cabinets, interconnect the seismic assemblies with the interconnection plate 870-51172 from the accessory kit 0M-95331.

Rear View




3. Remove the indicated screws.

Rear View




4. Remove the rear seismic bracket.

Rear View



5. Install the rear seismic bracket on the battery cabinet(s).


Rear View



Position and Interconnect the Battery Cabinets


NOTE: This procedure describes how to position and interconnect several battery cabinets. If your system only has one battery cabinet, you only need to follow step 2 and step 3.

1. Remove the side panels that are adjacent to the other battery cabinets.




2. Push the right-most battery cabinet into position. For seismic anchoring, ensure that the rear seismic bracket connects to the rear anchors.

Rear View





3. Lower the levelling feet until they connect with the floor - use a bubble-leveler to ensure that the cabinet is level.



- 4. Push the second right-most battery cabinet into position, align with the seismic anchoring (if any), and level the battery cabinet as described in step 2 and step 3.
- 5. Install the ten interconnection screws (five in the front and five in the rear) between the two battery cabinets.

NOTE: To reach the five interconnection screws in the rear of the leftmost battery cabinet, the left side panel can be removed. Reinstall the left side panel on the left-most battery cabinet after interconnection.






6. Push the third battery cabinet into position, align with the seismic anchoring (if any), level the battery cabinet, and interconnect with the other battery cabinets as described in step 2, step 3, and step 5. Continue until all the battery cabinets are in place, levelled, and interconnected.

Install the Front Seismic Anchoring

1. Install the front seismic bracket (front shipping bracket) on the battery cabinet.




2. Anchor the front seismic bracket to the floor using appropriate hardware for the floor type – the hole diameter in the front seismic bracket is ø14 mm. The minimum requirement is M12 strength grade 8.8 hardware.


NOTE: Floor anchoring bolts are not supplied.

Install the Battery Modules in the Battery Cabinet

Type A Battery Module



Type B Battery Module



AAWARNING

HAZARD OF INJURY AND ELECTRIC SHOCK

Be careful when installing and removing the battery modules (>17 kg).

Failure to follow these instructions can result in death, serious injury, or equipment damage.


1. Install the battery modules on the shelves from top to bottom.

NOTE: Pay special attention to the location of type A and type B battery modules.

Battery Configurations for Battery Cabinets with 17, 16, 13, and 10 Battery Modules



2. Reinstall the plate in front of the battery shelves.



Connect the Power Cables


AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Do not drill or punch holes with the gland plates installed and do not drill or punch holes in close proximity to the battery cabinet.

Failure to follow these instructions will result in death or serious injury.

1. Remove the gland plates.



2. Drill or punch holes for cables/conduits in the rear gland plate according to the label on the gland plate.

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Ensure that there are no sharp edges that can damage the cables.


Failure to follow these instructions will result in death or serious injury.


3. Install conduits (if applicable) and reinstall the gland plates.

- 4. Route the power cables through the gland plate and connect to the terminals:
 - a. Connect the PE cable to the PE terminal/Connect the EGC cable to the grounding terminal.
 - b. For installations with two hole cable lugs only, temporarily remove the protection cover.

NOTE: The protection cover must be reinstalled when the DC- cable has been connected.

c. Connect the DC+ and DC- cables to the DC+ and DC- terminals.






5. Connect the power cables in the UPS. If more battery cabinets are part of the solution, connect all battery cabinets to the UPS according to the diagram below.


NOTE: If the combined short circuit current of the battery cabinets exceeds the short circuit rating of the UPS, a pull box with fuses or an external box with a battery breaker must be installed. Please contact Schneider Electric for more information and refer to the submittal drawings for your specific UPS.

NOTE: Follow the correct wiring diagram based on your system.


2-Wire Connection




3-Wire Connection



6. Reinstall the two transparent covers.



Overview of Communication Interface



- A. TCP/IP
- B. DRY CONTACT ports
- C. SMPS I/O
- D. CAN I/O
- E. RS485
- F. System BMS CAN I/O
- G. DC OUT 1 and DC OUT 2
- H. Reset switch
- I. Start-up button
- J. DC IN 1 and DC IN 2
- K. Status LEDs
- L. CAN bus loop termination resistor switch
- M. CAN 1 port, CAN 2 port
- N. Module
- O. EPO
- P. PSU 1 LED
- Q. PSU 2 LED
- R. SG IO 1
- S. SG 10 2
- T. MCCB AUX 1
- U. MCCB AUX 2

Route the Signal Cables to the Switchgear, Rack BMS, and System BMS Ports

AADANGER


HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Do not drill or punch holes with the gland plates installed and do not drill or punch holes in close proximity to the battery cabinet.

Failure to follow these instructions will result in death or serious injury.

NOTE: Please refer to the UPS submittal drawings to get a complete overview of the connections before preparing for and routing the signal cables.

1. Remove the gland plates for signal cables.



2. Drill or punch holes for cables/conduits and install conduits (if applicable).

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Ensure that there are no sharp edges that can damage the cables.


Failure to follow these instructions will result in death or serious injury.

3. The provided SELV signal cable 0W13444 and the ELV signal cables 0W76929 and 0W13442 are 5 m (16.4 ft) long. You can extend the length of the three signal cables if the distance to the UPS is more than the expected 5 m (16.4 ft). Follow one of the instructions below:


Signal cable specifications

| 0W13444 | 4 conductors, 22 AWG, 600 V ETFE UL10086, strand, 90 °C | | |
|---------|--|--|--|
| 0W76929 | 2 conductors, 24 AWG, 600 V ETFE UL10086, double insulation, strand, 90 °C | | |
| 0W13442 | 2 conductors, 22 AWG, 600 V ETFE UL10086, double insulation, strand, 90°C | | |

 The provided signal cable is long enough to reach between the battery cabinet and the UPS: Remove the male adapter connector from the end of the signal cables and continue to the next step. OR



The provided signal cable is NOT long enough to reach between the battery cabinet and the UPS: Remove the female connector and the male adapter connector from the end of the signal cable, shorten the signal cable to 120 mm (4.7 in) length, and reattach the labels and the female connector and male adapter connector to the signal cable. Attach a signal cable³ (not provided) to the male adapter connector in the correct length to reach from the battery cabinet to the UPS. As an alternative, you can also crimp the signal cable extensions. Ensure that the crimp point is inside the battery cabinet, not in conduits or cable trays outside the battery cabinet.





^{3.} Select the extension signal cables according to the Signal cable specifications.

4. Route the SELV signal cable 0W13444 and the ELV signal cables 0W76929 and 0W13442 into the battery cabinet and to the switchgear ports. Do not connect the signal cables, Schneider Electric service will complete the connections during start-up.

With Provided Signal Cables


With Extended Signal Cables






5. Route the signal cable 0W76928, 0W76934, and 0W76972 through the openings in the sides of the battery cabinets and to the ports in the rack BMS and the switchgear ports. Do not connect the signal cables, Schneider Electric service will complete the connections during start-up.


NOTE: All cables between rack BMS and rack BMS as well as between system BMS and rack BMS are considered Class 2/SELV.



6. Reinstall the plate in front of the battery breaker.



- 7. Reinstall the front door of the battery cabinet.
- 8. Install the temperature sensor provided with the UPS above the battery cabinet, approximately 300 mm (12 in) from the top. Route the signal cable to the UPS and connect according to the instructions in the UPS installation manual.




NOTE: The temperature sensor measures the ambient temperature. Do not place the temperature sensor close to external heating or cooling equipment which may give an incorrect measurement of the ambient temperature.

Overview of Signal Cables between the Battery Cabinets and the Auxiliary Contacts in the UPS


The connection of auxiliary contacts is dependent on the number of battery breakers supported by the UPS. In the examples below two banks of battery breakers are supported.

NOTE: If the combined short circuit current of the battery cabinets exceeds the short circuit rating of the UPS, a pull box with fuses or an external box with a battery breaker must be installed. Please contact Schneider Electric for more information.

System with One Battery Cabinet



System with Two Battery Cabinets




2

3

Common

System with Four Battery Cabinets in Two Battery Banks



breaker

AUX 2


38 990-91430E-001

Overview of Signal Cables for Alarms and Battery Breaker Trip


In systems with more battery cabinets, only the system BMS of battery cabinet 1 (the battery cabinet closest to the UPS) is connected to the UPS. Remove signal cable 0W13441 between the SMPS I/O port and the DRY CONTACT ports on battery cabinet 2 and battery cabinet 3.

- SG IO 1: Used for sending signals for minor and major alarms to the UPS.
- SG IO 2: Used for receiving trip signal from the UPS.

System with One Battery Cabinet




System with Three Battery Cabinets in Two Battery Banks



Overview of CAN Bus Cables between the Battery Cabinets

NOTE: In systems with more battery cabinets, remove the cables 0W76935 from CAN 1 in the rack BMS to the System BMS CAN I/O in battery cabinet 2 and battery cabinet 3.

1. Route signal cable 0W76928 from CAN 2 port of battery cabinet 1 to the CAN 1 port of battery cabinet 2. Repeat for the remaining battery cabinets. Do not connect the CAN cables, Schneider Electric service will complete the connections during start-up.



Overview of EPO Signal Cables

Connect the Class 2/SELV signal cables from the building EPO to the rack BMS. Class 2/SELV circuits must be isolated from the primary circuitry. Do not connect any circuit to the EPO terminal block unless it can be confirmed that the circuit is Class 2/SELV.



Operation Procedures

Shut Down the Battery Solution

NOTE: This procedure is only for a short temporary shutdown of the battery solution. If the battery solution should remain shut down for a longer period, please contact Schneider Electric.

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

The battery cabinet contains an internal energy source. Hazardous voltage is still present after the battery breaker has been opened.


Failure to follow these instructions will result in death or serious injury.

1. Manually set the battery breaker of each individual battery cabinet to the OFF (open) position to disconnect the battery power from the UPS.


NOTE: The system BMS and rack BMS will still be operating.

Restart the Battery Solution

- 1. Perform the following steps on all battery cabinets in the battery solution.
 - Remove the cover in front of the start-up button and push the start-up button.



- The PSU2 LED and the POWER LED will turn on.
- The ABNORMAL and ALARM LEDs should remain off.




- b. Reinstall the cover in front of the start-up button.
- c. Set the battery breaker to the ON (closed) position.

Monitor the Battery System

NOTE: Schneider Electric uses the battery system monitoring software ITE/DCE to monitor the performance of the battery system. Please contact Schneider Electric application engineering team to obtain its installation instructions and operation instructions.

Download Data Log from the Data Log Kit (Optional)


1. Remove the cover plate from the data log kit.



 Connect a USB device to the USB port. Push and hold **DOWNLOAD** button for 50 milliseconds to 3 seconds until LED1 (USB) is turned on. LED1 (USB) is blinking (1 second interval) when data is being downloaded to the USB device.

NOTE: Recommended capacity of USB device is 32GB or more, and file system supports FAT32 (recommended) or NTFS.

NOTE: Download time takes up to about 80 minutes (eMMC data capacity 24GB, USB file system based on FAT32).




3. LED1 (USB) turns off when the download is complete. Reinstall the cover plate back to the data log kit.

Troubleshooting

Status LEDs


| LED | Battery Status | Description |
|-------------------------------|----------------|--|
| ABNORMAL CURRENT POWER ALARM | Normal | The battery breaker is in the OFF (open) position. |
| ABNORMAL CURRENT POWER ALARM | Normal | The battery breaker is in the ON (closed) position. |
| ABNORMAL CURRENT POWER ALARM | Normal | The batteries are being discharged. |
| ABNORMAL CURRENT POWER ALARM | Normal | The batteries are being recharged. |
| ABNORMAL CURRENT POWER ALARM | Major alarm | The battery breaker has tripped and is in the OFF (open) position. |
| ABNORMAL CURRENT POWER ALARM | Minor alarm | The battery breaker is in the ON (closed) position. |

PSU LEDs



- When the LED is green, the PSU is powered ON.
- When the LED is OFF, the PSU is powered OFF or inoperable.

Data Log Kit LEDs



- A. Network
- B. CAN
- C. USB
- D. Firmware

Blinking means 1 second interval. Flashing means 50 milliseconds interval.

| LED | Status | Description |
|---------------------------|---|---|
| Network CAN USB Firmware | CAN blinking Firmware blinking | CAN data is incoming. Firmware is operating. |
| Network CAN USB Firmware | CAN flashing Firmware flashing | Data is being reorganized due to setting change. Wait until reorganization is complete. |
| Network CAN USB Firmware | Network flashing CAN blinking Firmware blinking | Network is being used when using Data BMS user interface. |

| LED | Status | Description |
|---------------------------|---|--|
| Network CAN | USB blinking CAN flashing Firmware blinking | Data is being downloaded to USB device for backup. |
| USB Firmware Network CAN | Firmware blinking CAN off | Connection error. |
| USB Firmware | | |

Alarm List

Protection Protocols

Protection Protocol for Battery Cabinet with 17 Battery Modules

| No | Item | Lev- el | Set condition | Software set time (sec) | Battery breaker status ⁴ | Release condition | Time (sec) | Battery breaker status |
|----|--|------------|--|-------------------------------|---|--|---------------|------------------------------|
| 1 | Over voltage protection - cell | Major | Max cell ≥ 4.28 V | 5 | OFF | Max cell <4.25 V and press the reset switch | 5 | ON |
| 2 | Under voltage protection - cell | Major | Min cell ≤ 2.5 V | 3 | OFF | Min cell > 2.70 V and press the reset switch | 3 | ON |
| 3 | Over voltage protection - cabinet | Major | Cabinet voltage ≥ 582.08 V | 5 | OFF | Cabinet voltage < 578 V and press the reset switch | 5 | ON |
| 4 | Under voltage protection - cabinet | Major | Cabinet voltage ≤ 340 V | 3 | OFF | Cabinet voltage > 367.2 V and press the reset switch | 3 | ON |
| 5 | Cabinet cell voltage imbalance | Major | △Vcell ≥ 500 mV | 5 | OFF | △Vcell ≥ 50 mV | 5 | ON |
| 6 | Module cell voltage imbalance | Major | △Vcell ≥ 90 mV | 5 | OFF | △Vcell ≥ 30 mV | 5 | ON |
| 7 | Voltage sensing error (cabinet) | Minor | Cabinet V - cell sum V ≥ 40.8 V | 10 | ON | Cabinet V - cell sum V < 20.4 V and press the reset switch | 3 | ON |
| 8 | Voltage sensing error (module) | Minor | Module V - cell sum V ≥ 190 mV | 5 | ON | Module V - cell sum V < 190 mV and press the reset switch | 3 | ON |
| 9 | Over temperature protection | Major | Max temp ≥ 75 °C (167 ° F) | 3 | OFF | Max temp < 65 °C (149 ° F) and press the reset switch | 3 | ON |
| 10 | Under temperature protection | Minor | Min temp ≤ 0 °C (32 °F) | 3 | ON | Min temp > 5 °C (41 °F) and press the reset switch | 3 | ON |
| 11 | Temperature imbalance | Major | Max cell T - min cell T ≥ 40 °C (104 °F) | 30 | OFF | Max cell T - min cell T < 20 °C (68 °F) and press the reset switch | 3 | ON |
| 12 | Over current protection (charge) | Major | Level2 current ≥ 250 A | 2 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | (charge) | Major | Level1 current ≥ 200 A | 60 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| 13 | Over current protection | Major | Level4 current ≥ 600 A | 1 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | (discharge) | Major | Level3 current ≥ 540 A | 10 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | | Major | Level2 current ≥ 495 A | 30 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | | Major | Level1 current ≥ 470 A | 60 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| 14 | Communication lost (module ↔ cabinet) | Major | No communication | 30 | OFF | Communication reestablished and press the reset switch | - | ON |
| 15 | Communication lost (cabinet ↔ system) | Minor | No communication | 30 | ON | Communication reestablished and press the reset switch | - | ON |
| 16 | SW failure - battery breaker | Minor | Battery breaker OFF and current ≥ 2.4 A | 3 | ON | (Battery breaker OFF and (current < 2.4 A) | - | ON |

^{4.} The battery breaker status will switch from ON to OFF within three seconds after the software set time.

Protection Protocol for Battery Cabinet with 17 Battery Modules (Continued)

| No | Item | Lev- el | Set condition | Software set time (sec) | Battery breaker status ⁵ | Release condition | Time (sec) | Battery breaker status |
|----|--|------------|--|-------------------------------|---|--|---------------|------------------------------|
| | | | | | | and press the reset switch | | |
| 17 | SW sensor failure - battery breaker | Minor | Battery breaker contact ON = battery breaker trip ON | 3 | ON | (Battery breaker contact ≠ battery breaker trip) and press the reset switch | - | ON |
| 18 | Current sensing error | Minor | No communication with Current IC | 3 | ON | Communication with current IC OK | - | ON |
| 19 | Fuse failure | Minor | Fuse blown | 10 | ON | Fuse ON and press the reset switch | - | ON |

^{5.} The battery breaker status will switch from ON to OFF within three seconds after the software set time.

Protection Protocol for Battery Cabinet with 16 Battery Modules

| No | Item | Level | Set condition | Software set time (sec) | Battery breaker status ⁵ | Release condition | Time (sec) | Battery breaker status |
|----|---|-------|--|-------------------------|---|--|---------------|------------------------------|
| 1 | Over voltage protection - cell | Major | Max cell ≥ 4.28 V | 5 | OFF | Max cell < 4.25 V and press the reset switch | 5 | ON |
| 2 | Under voltage protection - cell | Major | Min cell ≤ 2.5 V | 3 | OFF | Min cell > 2.70 V and press the reset switch | 3 | ON |
| 3 | Over voltage protection - cabinet | Major | Cabinet voltage ≥ 547.84 V | 5 | OFF | Cabinet voltage < 544 V and press the reset switch | 5 | ON |
| 4 | Under voltage protection - cabinet | Major | Cabinet voltage ≤ 320 V | 3 | OFF | Cabinet voltage > 345.6 V and press the reset switch | 3 | ON |
| 5 | Cabinet cell voltage imbalance | Major | △Vcell ≥ 500 mV | 5 | OFF | △Vcell ≥ 50 mV | 5 | ON |
| 6 | Module cell voltage imbalance | Major | △Vcell ≥ 90 mV | 5 | OFF | △Vcell ≥ 30 mV | 5 | ON |
| 7 | Voltage sensing error (cabinet) | Minor | Cabinet V - cell sum V ≥ 38.4 V | 10 | ON | Cabinet V - cell sum V < 19.2 V and press the reset switch | 3 | ON |
| 8 | Voltage sensing error (module) | Minor | Module V - cell sum V ≥ 190 mV | 5 | ON | Module V - cell sum V < 190 mV and press the reset switch | 3 | ON |
| 9 | Over temperature protection | Major | Max temp ≥ 75 °C (167 ° F) | 3 | OFF | Max temp < 65 °C (149 ° F)and press the reset switch | 3 | ON |
| 10 | Under temperature protection | Minor | Min temp ≤ 0 °C (32 °F) | 3 | ON | Min temp > 5 °C (41 °F) and press the reset switch | 3 | ON |
| 11 | Temperature imbalance | Major | Max cell T - min cell T ≥ 40 °C (104 °F) | 30 | OFF | Max cell T - min cell T < 20 °C (68 °F) and press the reset switch | 3 | ON |
| 12 | Over current protection (charge) | Major | Level2 current ≥ 250 A | 2 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | (Glaige) | Major | Level1 current ≥ 200 A | 60 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| 13 | Over current protection (discharge) | Major | Level4 current ≥ 600 A | 1 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | (discriarge) | Major | Level3 current ≥ 540 A | 10 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | | Major | Level2 current ≥ 495 A | 30 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | | Major | Level1 current ≥ 470 A | 60 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| 14 | Communication lost (module ↔ cabinet) | Major | No communication | 30 | OFF | Communication reestablished and press the reset switch | - | ON |
| 15 | Communication lost (cabinet ↔ system) | Minor | No communication | 30 | ON | Communication reestablished and press the reset switch | - | ON |
| 16 | SW failure - battery breaker | Minor | Battery breaker OFF and current ≥ 2.4 A | 3 | ON | (Battery breaker OFF and (current < 2.4 A) and press the reset switch | - | ON |
| 17 | SW sensor failure - battery breaker | Minor | Battery breaker contact ON = battery breaker trip ON | 3 | ON | (Battery breaker contact ≠ battery breaker trip) and press the reset switch | - | ON |

^{5.} The battery breaker status will switch from ON to OFF within three seconds after the software set time.

Protection Protocol for Battery Cabinet with 16 Battery Modules (Continued)

| No | Item | Level | Set condition | Software set time (sec) | Battery breaker status ⁶ | Release condition | Time (sec) | Battery breaker status |
|----|-----------------------|-------|----------------------------------|-------------------------------|---|------------------------------------|---------------|------------------------------|
| 18 | Current sensing error | Minor | No communication with Current IC | 3 | ON | Communication with current IC OK | - | ON |
| 19 | Fuse failure | Minor | Fuse blown | 10 | ON | Fuse ON and press the reset switch | - | ON |

^{6.} The battery breaker status will switch from ON to OFF within three seconds after the software set time.

Protection Protocol for Battery Cabinet with 13 Battery Modules

| No | Item | Level | Set condition | Software set time (sec) | Battery breaker status ⁷ | Release condition | Time (sec) | Battery breaker status |
|----|---|-------|--|-------------------------------|---|--|---------------|------------------------------|
| 1 | Over voltage protection - cell | Major | Max cell ≥ 4.28 V | 5 | OFF | Max cell <4.25 V and press the reset switch | 5 | ON |
| 2 | Under voltage protection - cell | Major | Min cell ≤ 2.5 V | 3 | OFF | Min cell > 2.70 V and press the reset switch | 3 | ON |
| 3 | Over voltage protection - cabinet | Major | Cabinet voltage ≥ 445.12 V | 5 | OFF | Cabinet voltage < 442 V and press the reset switch | 5 | ON |
| 4 | Under voltage protection - cabinet | Major | Cabinet voltage ≤ 260 V | 3 | OFF | Cabinet voltage > 280.8 V and press the reset switch | 3 | ON |
| 5 | Cabinet cell voltage imbalance | Major | △Vcell ≥ 500 mV | 5 | OFF | △Vcell ≥ 50 mV | 5 | ON |
| 6 | Module cell voltage imbalance | Major | △Vcell ≥ 90 mV | 5 | OFF | △Vcell ≥ 30 mV | 5 | ON |
| 7 | Voltage sensing error (cabinet) | Minor | Cabinet V - cell sum V ≥ 31.2 V | 10 | ON | Cabinet V - cell sum V < 15.6 V and press the reset switch | 3 | ON |
| 8 | Voltage sensing error (module) | Minor | Module V - cell sum V ≥ 190 mV | 5 | ON | Module V - cell sum V < 190 mV and press the reset switch | 3 | ON |
| 9 | Over temperature protection | Major | Max temp ≥ 75 °C (167 ° F) | 3 | OFF | Max temp < 65 °C (149 ° F) and press the reset switch | 3 | ON |
| 10 | Under temperature protection | Minor | Min temp ≤ 0 °C (32 °F) | 3 | ON | Min temp > 5 °C (41 °F) and press the reset switch | 3 | ON |
| 11 | Temperature imbalance | Major | Max cell T - min cell T ≥ 40 °C (104 °F) | 30 | OFF | Max cell T - min cell T < 20 °C (68 °F) and press the reset switch | 3 | ON |
| 12 | Over current protection | Major | Level2 current ≥ 250 A | 2 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | (charge) | Major | Level1 current ≥ 200 A | 60 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| 13 | Over current protection | Major | Level4 current ≥ 600 A | 1 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | (discharge) | Major | Level3 current ≥ 540 A | 10 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | | Major | Level2 current ≥ 495 A | 30 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | | Major | Level1 current ≥ 470 A | 60 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| 14 | Communication lost (module ↔ cabinet) | Major | No communication | 30 | OFF | Communication reestablished and press the reset switch | - | ON |
| 15 | Communication lost (cabinet ↔ system) | Minor | No communication | 30 | ON | Communication reestablished and press the reset switch | - | ON |
| 16 | SW failure - battery breaker | Minor | Battery breaker OFF and current ≥ 2.4 A | 3 | ON | (Battery breaker OFF and (current < 2.4 A) and press the reset switch | - | ON |
| 17 | SW sensor failure - battery breaker | Minor | Battery breaker contact ON = battery breaker trip ON | 3 | ON | (Battery breaker contact ≠ battery breaker trip) and press the reset switch | - | ON |

^{7.} The battery breaker status will switch from ON to OFF within three seconds after the software set time.

Protection Protocol for Battery Cabinet with 13 Battery Modules (Continued)

| No | Item | Level | Set condition | Software set time (sec) | Battery breaker status ⁸ | Release condition | Time (sec) | Battery breaker status |
|----|-----------------------|-------|-------------------------------------|-------------------------------|---|------------------------------------|---------------|------------------------------|
| 18 | Current sensing error | Minor | No communication with Current IC | 3 | ON | Communication with current IC OK | - | ON |
| 19 | Fuse failure | Minor | Fuse blown | 10 | ON | Fuse ON and press the reset switch | - | ON |

^{8.} The battery breaker status will switch from ON to OFF within three seconds after the software set time.

Protection Protocol for Battery Cabinet with 10 Battery Modules

| No | Item | Level | Set condition | Software set time (sec) | Battery breaker status ⁹ | Release condition | Time (sec) | Battery breaker status |
|----|--|-------|--|-------------------------------|---|--|---------------|------------------------------|
| 1 | Over voltage protection - cell | Major | Max cell ≥ 4.28 V | 5 | OFF | Max cell <4.25 V and press the reset switch | 5 | ON |
| 2 | Under voltage protection - cell | Major | Min cell ≤ 2.5 V | 3 | OFF | Min cell > 2.70 V and press the reset switch | 3 | ON |
| 3 | Over voltage protection - cabinet | Major | Cabinet voltage ≥ 342.4 V | 5 | OFF | Cabinet voltage < 340 V and press the reset switch | 5 | ON |
| 4 | Under voltage protection - cabinet | Major | Cabinet voltage ≤ 200 V | 3 | OFF | Cabinet voltage > 216 V and press the reset switch | 3 | ON |
| 5 | Cabinet cell voltage imbalance | Major | △Vcell ≥ 500 mV | 5 | OFF | △Vcell ≥ 50 mV | 5 | ON |
| 6 | Module cell voltage imbalance | Major | △Vcell ≥ 90 mV | 5 | OFF | △Vcell ≥ 30 mV | 5 | ON |
| 7 | Voltage sensing error (cabinet) | Minor | Cabinet V - cell sum V ≥ 24 V | 10 | ON | Cabinet V - cell sum V < 12 V and press the reset switch | 3 | ON |
| 8 | Voltage sensing error (module) | Minor | Module V - cell sum V ≥ 190 mV | 5 | ON | Module V - cell sum V < 190 mV and press the reset switch | 3 | ON |
| 9 | Over temperature protection | Major | Max temp ≥ 75 °C (167 ° F) | 3 | OFF | Max temp < 65 °C (149 ° F) and press the reset switch | 3 | ON |
| 10 | Under temperature protection | Minor | Min temp ≤ 0 °C (32 °F) | 3 | ON | Min temp > 5 °C (41 °F) and press the reset switch | 3 | ON |
| 11 | Temperature imbalance | Major | Max cell T - min cell T ≥ 40 °C (104 °F) | 30 | OFF | Max cell T - min cell T < 20 °C (68 °F) and press the reset switch | 3 | ON |
| 12 | Over current protection | Major | Level2 current ≥ 250 A | 2 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | (charge) | Major | Level1 current ≥ 200 A | 60 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| 13 | Over current protection | Major | Level4 current ≥ 600 A | 1 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | (discharge) | Major | Level3 current ≥ 540 A | 10 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | | Major | Level2 current ≥ 495 A | 30 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| | | Major | Level1 current ≥ 470 A | 60 | OFF | Current < 10 A and press the reset switch | 3 | ON |
| 14 | Communication lost (module ↔ cabinet) | Major | No communication | 30 | OFF | Communication reestablished and press the reset switch | - | ON |
| 15 | Communication lost (cabinet ↔ system) | Minor | No communication | 30 | ON | Communication reestablished and press the reset switch | - | ON |
| 16 | SW failure - battery breaker | Minor | Battery breaker OFF and current ≥ 2.4 A | 3 | ON | (Battery breaker OFF and (current < 2.4 A) and press the reset switch | - | ON |
| 17 | SW sensor failure - battery breaker | Minor | Battery breaker contact ON = battery breaker trip ON | 3 | ON | (Battery breaker contact ≠ battery breaker trip) and press the reset switch | - | ON |

^{9.} The battery breaker status will switch from ON to OFF within three seconds after the software set time.


Protection Protocol for Battery Cabinet with 10 Battery Modules (Continued)

| No | Item | Level | Set condition | Software set time (sec) | Battery breaker status ¹⁰ | Release condition | Time (sec) | Battery breaker status |
|----|-----------------------|-------|-------------------------------------|-------------------------------|--|------------------------------------|---------------|------------------------------|
| 18 | Current sensing error | Minor | No communication with Current IC | 3 | ON | Communication with current IC OK | - | ON |
| 19 | Fuse failure | Minor | Fuse blown | 10 | ON | Fuse ON and press the reset switch | - | ON |


^{10.} The battery breaker status will switch from ON to OFF within three seconds after the software set time.

Decommission or Move the Battery Cabinet to a New Location

1. Lockout/Tagout the battery breaker in the OFF (open) position and open the two fuse holders in the battery cabinet.



- 2. Lockout/Tagout the power to the SMPS AC/DC converter upstream (if applicable).
- 3. Disconnect and remove all power cables from the battery cabinet. See Connect the Power Cables, page 28 for details.



- Disconnect and remove all signal cables from the battery cabinet. See Route the Signal Cables to the Switchgear, Rack BMS, and System BMS Ports, page 33 for details.
- Disconnect and remove power cables to the SMPS AC/DC converter (if applicable). Refer to the SMPS AC/DC converter installation manual for details.
- 6. Contact Schneider Electric for removal of the battery busbars and fuse kits. The battery busbars and fuse kits must only be removed by a Schneider Electric-certified field service representative or service partner.

7. Remove the batteries from the shelves. Recycle or reuse the batteries as appropriate.

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Servicing of batteries must only be performed or supervised by qualified personnel knowledgeable of batteries and the required precautions. Keep unqualified personnel away from batteries.

- · Recycle Lithium-ion batteries correctly.
- Dispose of the batteries in accordance with country and local regulations.

Failure to follow these instructions will result in death or serious injury.

- 8. Contact Schneider Electric for removal of the interconnection busbars between the cabinets. The interconnections busbars must only be removed by a Schneider Electric-certified field service representative or service partner.
- 9. Remove the seismic front and rear anchoring brackets from the cabinets. Save for reinstallation. See Install the Front Seismic Anchoring, page 25 and Install the Rear Seismic Anchoring, page 21 for details.
- 10. Close and lock the front door of the cabinets.
- 11. Raise the feet of the cabinets until the casters have full contact with the floor.
- 12. You can now move each cabinet individually by rolling it over the floor on the casters.

▲WARNING

TIPPING HAZARD

- The casters of the cabinet are exclusively for transport on flat, even, hard, and horizontal surfaces.
- The casters of the cabinet are intended for transport over short distances (i.e. inside the same building).
- Move at a slow pace and pay close attention on the floor conditions and the balance of the cabinet.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

13. For transport over longer distances or in conditions that are not suitable for the casters of the cabinet:

AWARNING

TIPPING HAZARD

For transport over longer distances or in conditions that are not suitable for the casters of the battery cabinet, ensure:

- that personnel performing the transport have necessary skills and have received adequate training;
- · to use appropriate tools to safely lift and transport the cabinet;
- to protect the product against damage by using appropriate protection (like wrapping or packaging).

Failure to follow these instructions can result in death, serious injury, or equipment damage.

AWARNING

TOP-HEAVY CABINET

The battery cabinet is top-heavy. Take appropriate precautions during handling and preparation for transport/shipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Transportation requirements:

- Mount the cabinet in a vertical position in the center of a suitable pallet.
 The pallet must be suitable for the weight of the cabinet.
- Use appropriate means of fixation to mount the cabinet to the pallet.

ADANGER

TIPPING HAZARD

- The cabinet must be appropriately fixed to the pallet immediately after being placed on the pallet.
- The fixation hardware must be strong enough to withstand vibrations and shocks during loading, transport, and unloading.

Failure to follow these instructions will result in death or serious injury.

AWARNING

UNEXPECTED EQUIPMENT BEHAVIOR

Do not lift the cabinet with a forklift/pallet truck directly on the frame as it may bend or damage the frame.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

- 14. Perform one of the following:
 - Decommission the battery cabinet, OR
 - Move the battery cabinet to a new location to install it.

15. Only for installing the battery cabinet in a new location: Follow the installation manual to install the battery cabinet in the new location. See Installation Procedure, page 18 for installation overview. Startup must only be performed by Schneider Electric.

AADANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Startup must only be performed by Schneider Electric.

Failure to follow these instructions will result in death or serious injury.

Schneider Electric 35 rue Joseph Monier 92500 Rueil Malmaison France

+ 33 (0) 1 41 29 70 00



As standards, specifications, and design change from time to time, please ask for confirmation of the information given in this publication. $\frac{1}{2} \int_{-\infty}^{\infty} \frac{1}{2} \int_{-\infty}^{\infty} \frac{$

© 2021 – 2024 Schneider Electric. All rights reserved.

990-91430E-001