

PacT Series

Service Interface for MasterPacT NT/NW, ComPacT, PowerPacT, and EasyPacT Circuit Breakers

Firmware Release Notes

PacT Series offers world-class breakers and switches.

DOCA0176EN-08
02/2025



Legal Information

The information provided in this document contains general descriptions, technical characteristics and/or recommendations related to products/solutions.

This document is not intended as a substitute for a detailed study or operational and site-specific development or schematic plan. It is not to be used for determining suitability or reliability of the products/solutions for specific user applications. It is the duty of any such user to perform or have any professional expert of its choice (integrator, specifier or the like) perform the appropriate and comprehensive risk analysis, evaluation and testing of the products/solutions with respect to the relevant specific application or use thereof.

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this document are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owner.

This document and its content are protected under applicable copyright laws and provided for informative use only. No part of this document may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the document or its content, except for a non-exclusive and personal license to consult it on an "as is" basis.

Schneider Electric reserves the right to make changes or updates with respect to or in the content of this document or the format thereof, at any time without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this document, as well as any non-intended use or misuse of the content thereof.

Table of Contents

Safety Information.....	5
Cybersecurity Safety Notice.....	6
About the Document.....	7
Introduction to Service Interface.....	11
Overview	11
Firmware Release History	11
Firmware Update Policy	12
Firmware Update with EcoStruxure Power Commission Software	12
Firmware Versions.....	13
Firmware Version 001.001.052	13
Firmware Version 001.001.049	13
Firmware Version 001.001.040	14
Firmware Version 001.001.037	14
Firmware Version 001.001.035	14
Firmware Version 001.001.032	14
Firmware Version 001.001.030	14
Firmware Version 001.001.027	14
Firmware Version 001.001.025	15
Firmware Version 001.001.019	15
Firmware Version 001.001.015	16
Firmware Version 001.001.012	16
Firmware Version 001.001.008	16
Firmware Version 001.000.003	16
Firmware Version 001.000.001	16
Firmware Version 001.000.000	17

Safety Information

Important Information

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

⚠ DANGER
DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.
⚠ WARNING
WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
⚠ CAUTION
CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE
NOTICE is used to address practices not related to physical injury.

Please Note

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified personnel is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

Cybersecurity Safety Notice

⚠ WARNING

POTENTIAL COMPROMISE OF SYSTEM AVAILABILITY, INTEGRITY, AND CONFIDENTIALITY

- Change default passwords at first use to help prevent unauthorized access to device settings, controls, and information.
- Disable unused ports/services and default accounts to help minimize pathways for malicious attackers.
- Place networked devices behind multiple layers of cyber defenses (such as firewalls, network segmentation, and network intrusion detection and protection).
- Use cybersecurity best practices (for example, least privilege, separation of duties) to help prevent unauthorized exposure, loss, modification of data and logs, or interruption of services.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

About the Document

PacT Series Master Range

Future-proof your installation with Schneider Electric's low-voltage and medium-voltage PacT Series. Built on legendary Schneider Electric innovation, the PacT Series comprises world-class circuit breakers, switches, residual current devices and fuses, for all standard and specific applications. Experience robust performance with PacT Series within the EcoStruxure-ready switchgear, from 16 to 6300 A in low-voltage and up to 40.5 kV in medium-voltage.

Document Scope

This document provides the firmware version history of Service Interface.

Use this document to determine whether an update to the latest version of the Service Interface is relevant for your application.

Validity Note

This document applies to Service Interface used with MicroLogic™ trip units mounted in the following low voltage circuit breakers:

- MasterPacT™ NT/NW circuit breakers
- EasyPacT™ MVS circuit breakers
- ComPacT™ NS circuit breakers
- PowerPacT™ P- and R- frame circuit breakers
- ComPacT™ NSX circuit breakers
- PowerPacT™ H-, J-, and L-frame circuit breakers

NOTE:

- The information related to the new generation of ComPacT NSX and PowerPacT H-, J-, and L-frame circuit breakers in this guide applies to the existing range ComPact NSX and PowerPact H-, J-, and L-frame circuit breakers also. The exceptions are mentioned wherever applicable.
- The information related to the new generation of ComPacT NS and PowerPacT P- and R-frame circuit breakers in this guide applies to the existing range ComPact NS and PowerPact P- and R-frame circuit breakers also. The exceptions are mentioned wherever applicable.

General Cybersecurity Information

In recent years, the growing number of networked machines and production plants has seen a corresponding increase in the potential for cyber threats, such as unauthorized access, data breaches, and operational disruptions. You must, therefore, consider all possible cybersecurity measures to help protect assets and systems against such threats.

To help keep your Schneider Electric products secure and protected, it is in your best interest to implement the cybersecurity best practices as described in the Cybersecurity Best Practices document.

Schneider Electric provides additional information and assistance:

- [Subscribe to the Schneider Electric security newsletter.](#)
- [Visit the Cybersecurity Support Portal web page to:](#)
 - [Find Security Notifications.](#)
 - [Report vulnerabilities and incidents.](#)
- [Visit the Schneider Electric Cybersecurity and Data Protection Posture web page to:](#)
 - [Access the cybersecurity posture.](#)
 - [Learn more about cybersecurity in the cybersecurity academy.](#)
 - [Explore the cybersecurity services from Schneider Electric.](#)

Related Documents for IEC Devices

The following table lists documents for IEC devices compatible with the Service Interface with the latest firmware version.

Title of documentation	Publication date	Reference number
<i>Service Interface - Instruction Sheet</i>	01/2023	GDE78167
<i>Service Interface for MasterPacT NT/NW, ComPacT, PowerPacT, and EasyPacT Circuit Breakers - User Guide</i>	09/2024	DOCA0170EN DOCA0170ES DOCA0170FR DOCA0170ZH
<i>MasterPacT NT - Circuit Breakers and Switch-Disconnectors from 630 to 1600 A - User Guide</i>	04/2016	51201116AA (EN) EAV16739 (ES) 51201115AA (FR)
<i>MasterPacT NW - Circuit Breakers and Switch-Disconnectors from 800 to 6300 A - User Guide</i>	06/2022	04443720AA (EN) EAV16740 (ES) 04443719AA (FR)
<i>MasterPacT NT/NW - Circuit Breakers and Switch-Disconnectors - Maintenance Guide</i>	12/2020	LVPED508016EN LVPED508016FR
<i>MasterPacT NT/NW - Basic and Standard End-User Maintenance Procedures</i>	06/2022	HRB16483EN HRB16483FR
<i>ComPacT NS - MicroLogic Trip Units - User Guide</i>	01/2022	DOCA0217EN DOCA0217ES DOCA0217FR

Title of documentation	Publication date	Reference number
		DOCA0217ZH
<i>ComPacT NS - MicroLogic A/E Trip Units - User Guide</i>	01/2022	DOCA0218EN DOCA0218ES DOCA0218FR DOCA0218ZH
<i>ComPacT NS - MicroLogic P Trip Units - User Guide</i>	01/2022	DOCA0219EN DOCA0219ES DOCA0219FR DOCA0219ZH
<i>ComPacT NS - Circuit Breakers and Switch-Disconnectors - User Guide</i>	01/2022	DOCA0221EN DOCA0221ES DOCA0221FR DOCA0221ZH
<i>ComPacT NSX - Circuit Breakers and Switch-Disconnectors - User Guide</i>	06/2024	DOCA0187EN DOCA0187ES DOCA0187FR DOCA0187ZH
<i>ComPacT NSX - MicroLogic 5/6/7 Electronic Trip Units - User Guide</i>	06/2024	DOCA0188EN DOCA0188ES DOCA0188FR DOCA0188ZH
<i>EasyPacT MVS - User Manual</i>	07/2023	MVS21734

You can download these technical publications and other technical information from our website at www.se.com/ww/en/download/.

Related Documents for UL/ANSI Devices

The following table lists documents for UL/ANSI devices compatible with the Service Interface with the latest firmware version.

Title of documentation	Publication date	Reference number
<i>Service Interface - Instruction Sheet</i>	01/2023	GDE78167
<i>Service Interface for MasterPacT NT/NW, ComPacT, PowerPacT, and EasyPacT Circuit Breakers - User Guide</i>	09/2024	DOCA0170EN DOCA0170ES DOCA0170FR DOCA0170ZH
<i>MasterPacT NT Low-Voltage Power/Insulated Case Circuit Breaker - User Guide</i>	06/2015	0613IB1209 (EN, ES, FR)
<i>MasterPacT NW Low-Voltage Power/Insulated Case Circuit Breaker - User Guide</i>	06/2015	0613IB1204 (EN, ES, FR)
<i>PowerPacT R -Frame Circuit Breakers - Instruction Bulletin</i>	06/2023	48049-243-04 (EN, ES, FR)

Title of documentation	Publication date	Reference number
<i>PowerPacT P -Frame Circuit Breakers - Instruction Bulletin</i>	06/2023	48049-148-05 (EN, ES, FR)
<i>PowerPacT P -Frame Drawout Circuit Breakers - Instruction Bulletin</i>	06/2023	48049-336-02 (EN, ES, FR)
<i>PowerPacT H-, J-, and L-Frame Circuit Breakers with MicroLogic Trip Units - User Guide</i>	01/2020	48940-313-01 (EN, ES, FR)

You can download these technical publications and other technical information from our website at www.se.com/ww/en/download/.

Information on Non-Inclusive or Insensitive Terminology

As a responsible, inclusive company, Schneider Electric is constantly updating its communications and products that contain non-inclusive or insensitive terminology. However, despite these efforts, our content may still contain terms that are deemed inappropriate by some customers.

Introduction to Service Interface

Overview

The Service Interface with part number LV485500 is a portable instrument for field testing.

The Service Interface is used:

- For configuration of Enerlin'X devices.
- For testing and configuration of MicroLogic™ trip units mounted in the following low voltage circuit breakers:
 - MasterPacT™ NT/NW circuit breakers
 - EasyPacT™ MVS circuit breakers
 - ComPacT™ NS circuit breakers
 - PowerPacT™ P- and R- frame circuit breakers
 - ComPacT™ NSX circuit breakers
 - PowerPacT™ H-, J-, and L-frame circuit breakers

NOTE:

- The information related to the new generation of ComPacT NSX and PowerPacT H-, J-, and L-frame circuit breakers in this guide applies to the existing range ComPacT NSX and PowerPacT H-, J-, and L-frame circuit breakers also. The exceptions are mentioned wherever applicable.
- The information related to the new generation of ComPacT NS and PowerPacT P- and R-frame circuit breakers in this guide applies to the existing range ComPacT NS and PowerPacT P- and R-frame circuit breakers also. The exceptions are mentioned wherever applicable.
- These new ranges are based on the same technical and dimensional architecture as that of the existing range of circuit breakers.

EcoStruxure™ Power Commission (EPC) is a global software with test functions features for testing the circuit breakers and communication accessories through the Service Interface.

Firmware Release History

The following table indicates the release history of Service Interface firmware.

Date	Firmware version	Availability
February 2025	001.001.052	Digital release in EPC
October 2024	001.001.049	Obsolete
November 2023	001.001.040	Obsolete
July 2023	001.001.037	Obsolete
May 2023	001.001.035	Obsolete
April 2023	001.001.032	Obsolete
December 2022	001.001.030	Obsolete
November 2022	001.001.025	Obsolete
April 2022	001.001.019	Obsolete
January 2022	001.001.015	Obsolete
December 2021	001.001.012	Obsolete

Date	Firmware version	Availability
October 2021	001.001.008	Obsolete
August 2021	001.000.003	Obsolete
October 2020	001.000.001	Obsolete
August 2020	001.000.000	Obsolete

Firmware Update Policy

Firmware update is recommended to benefit from the latest features and potential bug fixes. Do not update the firmware to the latest version, if the latest features are not required for your application and no bug fixes are provided.

Use this release note to determine whether an update to the latest version of the firmware is relevant for your application.

For more information about the firmware update policy and the firmware compatibility between devices, refer to *DOCA0155EN MicroLogic Trip Units and Control Units - Firmware History*.

Firmware Update with EcoStruxure Power Commission Software

Use the latest version of EcoStruxure Power Commission (EPC) software to update the device with the latest firmware version available.

Click [here](#) for the latest version of EPC software.

For more information on the use of EPC software, refer to *EcoStruxure Power Commission Online Help*.

Firmware Versions

Firmware Version 001.001.052

New Features

The following status are added to test port LED in the Service Interface to identify the unsuccessful connection between Service Interface and circuit breakers:

LED indication	LED color	Status description
FLASH (every 2 s)	Green	Unsuccessful connection between Service Interface and MicroLogic trip unit mounted in the following circuit breakers with a LV485512SP cable: <ul style="list-style-type: none"> • MasterPacT NT/NW • EasyPacT MVS • ComPacT NS • PowerPacT P- and R-frame
	Blue	Unsuccessful connection between Service Interface and MicroLogic trip unit mounted in the following circuit breakers with a LV485513SP cable: <ul style="list-style-type: none"> • ComPacT NSX • PowerPacT H-, J-, or L-frame Unsuccessful connection between Service Interface and an Enerlin'X device with a LV485514SPcable.

The possible reasons for unsuccessful connection are:

- The cable is inoperative.
- The cable is not properly connected to the trip unit.
- The communication between the Service Interface and a trip unit or an Enerlin'X device is unstable.

For more information on the other test port LED status, refer to the *Service Interface for MasterPacT NT/NW, ComPacT, PowerPacT, and EasyPacT Circuit Breakers - User Guide*.

Bug Fixed

The following circuit breakers were not discovered in EPC when the Service Interface was connected to the MicroLogic trip units 1.2, 1.3, 2.2, 2.3, 3.2, 3.3, 4.2, 4.3, or 4.3 AL, which are mounted in the:

- ComPacT NSX circuit breakers
- PowerPacT H-, J-, and L-frame circuit breakers

Firmware Version 001.001.049

New Features

Performance enhancement

Firmware Version 001.001.040

New Features

Alarm simulation for ComPacT NSX and PowerPacT H-, J-, and L-Frame circuit breakers.

Bugs Fixed

Rectification of a bug in the Earth leakage current (IVigi) trip detection.

Firmware Version 001.001.037

New Features

The following features are added:

- Integration of new registers.
- Motor variants for ComPacT NSX circuit breakers trip time correction.

Firmware Version 001.001.035

New Features

Addition of devices compatible with Service Interface:

- MicroLogic trip units for ComPacT NSX circuit breakers
- MicroLogic trip units for PowerPacT H-, J-, and L- frame circuit breakers

Firmware Version 001.001.032

New Features

Performance enhancement

Firmware Version 001.001.030

Integration of new registers.

Firmware Version 001.001.027

Bugs Fixed

The following bugs are fixed:

- Enhancement in protection settings on MicroLogic 4.2 trip unit in ComPacT NSX and PowerPacT H-, J-, and L- frame circuit breakers.
- Improvement of identification of the cable to be connected to the Service Interface.

Firmware Version 001.001.025

New Features

The Service Interface can be used for updating firmware and testing the MicroLogic 5 A/E, MicroLogic 6 A/E, and MicroLogic 7 E trip units mounted in the following low voltage circuit breakers:

- ComPacT NSX circuit breakers
- PowerPacT H-, J-, and L- frame circuit breakers

The Service Interface can be used for testing the MicroLogic trip units mounted in the following low voltage circuit breakers:

- ComPacT NSX circuit breakers
- PowerPacT H-, J-, and L-frame circuit breakers

The following tests can be performed through the Service Interface:

- Zone-Selective Interlocking (ZSI) test
- Preparation for primary injection tests

The Service Interface can be used for updating firmware and configuring Enerlin'X devices.

Bugs Fixed

The following bugs are fixed:

- Refinement in communication during injection tests being performed.
- Rectification in trip time calculation.

Firmware Version 001.001.019

New Features

The Service Interface can be used for testing and configuring the MicroLogic 5 A/E, MicroLogic 6 A/E, and MicroLogic 7 E trip units mounted in the following low voltage circuit breakers:

- ComPacT NSX circuit breakers
- PowerPacT H-, J-, and L-frame circuit breakers

Automatic trip curve test with pre-configured test points can be performed through the Service Interface.

Firmware Version 001.001.015

New Features

The Service Interface can be used for testing and configuring the MicroLogic 5.2 B and 5.3 B trip units mounted in the following low voltage circuit breakers:

- ComPacT NSX circuit breakers
- PowerPacT H-, J-, and L-frame circuit breakers

The following tests can be performed through the Service Interface:

- Automatic trip curve test with pre-configured test points
- Automatic trip curve test with custom test points

The Service Interface can be used for configuring the MicroLogic 5 A/E, 6 A/E, and 7 E trip units mounted in the following low voltage circuit breakers:

- ComPacT NSX circuit breakers
- PowerPacT H-, J-, and L-frame circuit breakers

Firmware Version 001.001.012

Bug Fixed

Automatic trip curve test did not trip MasterPacT NW4000b–6300 circuit breakers. Bug introduced in firmware version 001.001.008.

Firmware Version 001.001.008

Bugs Fixed

During automatic trip curve test on MicroLogic trip unit:

- Trip did not occur on the circuit breaker due to injection time out.
- Trip occurred but the trip time was not displayed properly.

Firmware Version 001.000.003

Bugs Fixed

The following bugs are fixed:

- Algorithm was not able to support different Mitop coils.
- EcoStruxure Power Commission register mapping was incorrect for the circuit breakers manufactured prior to 2007.

Firmware Version 001.000.001

Bugs Fixed

Algorithm corrections were done to improve the test functions.

Firmware Version 001.000.000

New Features

The Service Interface can be used for testing the following MicroLogic trip units:

- non-communicating MicroLogic trip units
- communicating MicroLogic A, E, P, and H trip units

when they are mounted in the following low voltage circuit breakers:

- MasterPacT NT/NW circuit breakers
- EasyPacT MVS circuit breakers
- ComPacT NS circuit breakers
- PowerPacT P- and R- frame circuit breakers

The following tests can be performed using the Service Interface:

- Automatic trip curve tests
 - with preconfigured test points
 - with custom test points
- Zone-Selective Interlocking (ZSI) test
- Device check up (Force trip test)
- Preparation for primary injection tests:
 - Reset thermal memory
 - Inhibit ground-fault protection

Schneider Electric
35 rue Joseph Monier
92500 Rueil Malmaison
France

+ 33 (0) 1 41 29 70 00

www.se.com

As standards, specifications, and design change from time to time, please ask for confirmation of the information given in this publication.

© 2025 – Schneider Electric. All rights reserved.

DOCA0176EN-08