

Wiser wireless relay for build in (Puck)

Device User Guide

Information about features and functionality of the devices.

02/2023



Legal Information

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this guide are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owners.

This guide and its content are protected under applicable copyright laws and furnished for informational use only. No part of this guide may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the guide or its content, except for a non-exclusive and personal license to consult it on an "as is" basis. Schneider Electric products and equipment should be installed, operated, serviced, and maintained only by qualified personnel.

As standards, specifications, and designs change from time to time, information contained in this guide may be subject to change without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this material or consequences arising out of or resulting from the use of the information contained herein.

Table of Contents

| | |
|--|----|
| Safety information | 4 |
| Wiser wireless relay for build in (Puck)..... | 5 |
| For your safety | 5 |
| About the device..... | 6 |
| Installing the device | 6 |
| Testing the device..... | 6 |
| Pairing the device with Wiser Gateway | 7 |
| Pairing device manually..... | 7 |
| Pairing device with auto scan | 8 |
| Configuring the device | 9 |
| Changing the device icon | 9 |
| Renaming the device | 10 |
| Changing the device location | 10 |
| Removing the device | 11 |
| Resetting the device | 12 |
| Using the device | 12 |
| Manual operation | 12 |
| Turning the light switch On/Off using app | 12 |
| Setting up a schedule..... | 12 |
| Creating a moment | 13 |
| Creating an automation | 15 |
| LED indication..... | 20 |
| Troubleshooting | 20 |
| Technical data | 20 |
| Compliance..... | 22 |
| Compliance information for Green Premium products..... | 22 |
| Trademarks..... | 22 |

Safety information

Important information

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this manual or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that accompany this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

Failure to follow these instructions will result in death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

Wiser wireless relay for build in (Puck)



550B1011

For your safety

⚡⚠ DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

Safe electrical installation must be carried out only by skilled professionals. Skilled professionals must prove profound knowledge in the following areas:

- Connecting to installation networks.
- Connecting several electrical devices.
- Laying electric cables.
- Safety standards, local wiring rules and regulations.

Failure to follow these instructions will result in death or serious injury.

⚠ DANGER

HAZARD OF ELECTRIC SHOCK

- Make sure that the terminal connection area does not come in contact with the metallic parts of any device installed in the same location.
- Do not short the outputs to neutral.
- The switch contact and live conductor connection must be separated from one another by a 240 VAC basic insulation.

Failure to follow these instructions will result in death or serious injury.

⚠ WARNING

HAZARD OF ELECTRIC SHOCK

- Observe the regulations for working on live parts.
- Only actuate the device buttons using insulated auxiliary equipment that meets the requirements of EN 60900.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

About the device

The Wiser wireless relay for build in (hereinafter referred to as **Puck/Micro Module Light Switch**) combines the advantages of smart switch functionality with ordinary mechanical push-button switches. It transforms a conventional switch into a connected device that can be controlled from the switch or through the Wiser app. It can switch ohmic, inductive or capacitive loads.

IMPORTANT: Do not control any devices that depend on a permanent power supply.

Installing the device

Refer to the installation instruction supplied with this product.

See Wiser wireless relay for build in (Puck).

Testing the device

Before using the puck, manually test the puck and make sure that it works when connected to the devices.


⚠ WARNING

HAZARD OF ELECTRIC SHOCK

- Observe the regulations for working on live parts.
- Only actuate the device buttons using insulated auxiliary equipment that meets the requirements of EN 60900.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Short press the test button once, the connected device turns On/Off.





Pairing the device with Wiser Gateway

Using the Wiser app, first pair your device with the **Wiser Gateway** to access and control the device. You can either add the device manually or do an auto-scan to pair it.

Pairing device manually

To pair the device manually:


1. On **Home** page, tap **+**.
2. Tap  and select the **Wiser Hub** on the slide-up menu.
3. Select an option to add the device (A):
 - **Add Device with Install Code**
 - **Add Device without Install Code**



TIP: It is recommended to add the device with install code.

4. To pair the device with an install code, tap **Add Device with Install Code** to display the slide-up menu. Select any one of the options (B):
 - **Scan Install Code:** you can scan the device for the install code.
 - **Enter Install Code Manually:** you can manually enter the install code from the device.


After scanning or entering the install code, proceed to **Step 6**.



5. To pair the device without install code, tap **Add Device without Install Code**.

6. Select any one of the options to add the device:

- Short press the S/R (setup/reset) button 3 times (<0,5 s) on the Puck with a screwdriver.
- Short press the push button 3 times.




The LED blinks orange.

NOTE: If the puck is located behind the push button, the status LED is not visible.

7. In the app, select **Confirm LED is flashing orange** and tap **Start configuration (C)**.

Wait for a few seconds until the LED turns green. You can also see in the app that the device is joined.

8. Once the device is added in the app, tap **Done**.

Pairing device with auto scan

Pairing the device with auto scan automatically discovers the device when the corresponding device is powered on.

1. On the **Home** page, tap **+**.
2. Tap **Auto scan > Confirm**.
3. Enable permissions to **Access location** and **Wi-Fi** for scanning device and tap **Start scanning**.

NOTE: If you have multiple hubs, do Step 4 or proceed to Step 5.


4. Tap **Select hub** and select the from the slide-up menu.

5. Short press the setup/reset button 3 times (< 0,5 s) and wait for a few seconds until the device search is complete.

The LED blinks orange.

TIP: If you want to pair multiple devices at once, perform step 5 on each device and wait for a few seconds for them to be detected.

6. Tap **Next** (A) and select **Micromodule Switch**.





7. Once the device is added successfully, tap **Done**.


Configuring the device

Changing the device icon

You can change the device icon using the Wiser app.



1. On the **Home** page, select the device for which you wish to change the icon.
2. At the top-right corner of the screen, tap .
3. Tap edit  next to the device name.
4. Tap **Icon** to view the menu.


5. In the slide-up menu, select any one of the following (A) to change the device icon:
- **Take photo** - allows you to click a photo from the mobile camera.
 - **Select from Icon Library** - allows you to select an icon from the app library.
 - **Select from Album** - allows you to select a photo from the mobile gallery.



Renaming the device



You can rename the device using the Wiser app.


1. On the **Home** page, select the device for which you wish to rename.
2. At the top-right corner of the screen, tap .
3. Tap edit  next to the device name.
4. Tap **Name**, enter the new name (A) and then tap **Save**.



Changing the device location


You can change the device location using the Wiser app.


1. On the **Home** page, select the device for which you wish to change the location.
2. At the top-right corner of the screen, tap .
3. Tap edit  next to the device name.
4. Tap **Location**.
5. Select the desired location from the list (A) and then tap **Save**.



Removing the device

Using the app, you can remove a device from the device list.
To remove the device:

1. On the **Home** page, tap **All devices > Micromodule Switch**.
2. Tap  to display more details.
3. Tap **Remove and Factory Reset Device** (A).



TIP: On the **Home** page, tap and hold the **Micromodule Switch** to remove the device.

NOTE:

- Removing the device will reset the Puck. After reset the LED turns orange indicating that the Puck is ready to pair with another network.
- If there is a problem while pairing or resetting the Puck, refer to **Resetting the device manually**, page 12.

Resetting the device


You can reset the device to factory default manually.

1. Short press ($<0,5$ s) the Setup/Reset button 3 times and then long press the Setup/Reset button once for 10 s to reset the Puck to factory default mode.
or
Short press the push button 3 times and then long press the push button once for 10 s.
2. After 10 s, LED starts blinking red then release the operation button.

NOTE: All configuration data, user data, and network data are deleted.
After which

- No connectivity to other devices or rooms

The LED stops blinking upon successful reset of the device.
The Puck restarts and blinks green for a few seconds.




Using the device

Manual operation

When the puck is connected to a mechanical push button, the connected devices can be controlled manually by short pressing the push button.

NOTE: When the puck is installed inside the wall box, the status LED is not visible while using the puck.



Turning the light switch On/Off using app

Using the app, you can turn on/off the light switch remotely.

1. On the **Home** page, tap **All devices**.
2. In **Micromodule Switch** tap on  to turn on/off the light switch.

Setting up a schedule


The device can be fully controlled by schedule. Once the schedule is set, the device operates at a given time.

1. In the device control panel, tap **Schedule** > **Add Schedule** to add a schedule.

2. In **Add Schedule** menu, set the time (A).

NOTE: The Schedule works according to the time zone where the device is located.



3. Tap **Repeat** (B) to select the days you want to set the schedule.
4. Tap **Note** (C), enter the note and tap **Confirm**.
5. Tap the toggle switch (D) to turn on the **Notification** for the schedule. The app will send a notification that the scheduled task is executed at the scheduled time.
6. Tap **Switch** (E) and select any option, **On** or **Off**.





7. Tap **Save**.

Creating a moment

A Moment allows you to group multiple actions that are usually done together. Using the Wiser app, you can create moments based on your needs.


1. On the **Home** page, tap .
2. Go to **Moment** > **+** to create a moment.
3. Tap **Edit name**  (A), enter the name of the moment and tap **Save**.


TIP: You can choose the cover image that represents your moment by tapping .



4. In the **Action** section, tap **Add task** (B) to open the slide-up menu.


5. In the **Add task** menu, you can do either or all of the following actions (C):
- **Run the device** - Select the devices that you want in a moment.
 - **Select Automation** - Select the automation that you want to enable or disable.
 - **Delay** - Set the delay time.

NOTE: You can add one or more actions using .




6. Tap **Run the device** > **Micromodule Switch**.

7. Tap on **Switch** and select either **On** / **Off** / **Reverse Switch** and tap **Save**.



8. Tap **Next** and once the actions are set, tap **Save**.




Editing a moment

To edit a moment:

1. On the **Moment** tab, locate the moment you want to edit and tap **...**.
2. On the **Edit** page, you can tap each item (such as dimmer, shutter, delay, temperature, etc.) to change the settings.

TIP:

- You can add one or more actions using .
- To delete an existing action, slide the each item towards left and tap **Delete**.

Deleting a moment



To delete a moment:


1. On the **Moment** tab, locate the moment that you want to delete and then tap **...**.
2. Tap **Delete** and tap **Ok**.


NOTE: After deleting a moment, the device action can no longer be triggered.

Creating an automation


An automation allows you to group multiple actions that are usually done together, triggered automatically or at scheduled times. By using the Wiser app, you can create automations based on your needs.

1. On the **Home** page, tap the .
2. Go to **Automation** > **+** to create an automation.
3. Tap **Edit name**  (A), enter the name of the automation and tap **Save**.


TIP: You can choose the cover image that represents your automation by tapping .




4. Tap **Any condition is met** to select any one of the condition type (B):
 - **All conditions are met** - The automation is triggered when all the conditions are met
 - **Any condition is met** - The automation is triggered when at least one condition is met




5. Tap **Add Condition** to open the slide-up menu.
6. In the **Add Condition** menu, you can do either or all of the following options (C):
 - **When weather changes** - Select the various weather settings.
 - **Schedule** - Set the time and day.
 - **When device status changes** - Select the device and it's function.

NOTE: You can add one or more conditions using .



7. Tap **When device status changes** > **Switch** and select either functions:


- **On** - Turn on the switch.
- **Off** - Turn off the switch.
- **Reverse Switch** - Toggle the last state of the switch.




8. Tap **Add task** to open the slide-up menu.


9. In the **Add task** menu, you can do either or all of the following options (D):

- **Run the device** - Select the devices that you want to trigger.
- **Moment or Automation** - Select the moment which you want to trigger or select the automation that you want to enable or disable.
- **Send notification** - Turn on notification for the automation.
- **Delay** - Set the delay time.

NOTE: You can add one or more actions using .




10. Tap on **Effective period** to set the time range for the automation. You can select any one of the following (E):
- **All-day** - 24 hours
 - **Daytime** - From sunrise to sunset
 - **Night** - From sunset to sunrise
 - **Custom** - User defined time period




11. Once all the actions and conditions are set, tap **Save**.
Once the automation is saved, it is visible on the **Automation** tab. You can tap the toggle switch on the automation to enable it.

Example of an automation


This demonstration shows you how to create an automation to turn off the light switch at the scheduled time.

1. Go to **Automation** > **+** to create an automation.
2. Tap **Edit name**, enter the name of the automation and tap **Save**.
TIP: You can choose the cover image that best represents your automation by tapping .
3. Tap **Add Condition** > **Schedule**.
 - Tap **Repeat** (A), select the days you want to set the schedule and tap **Save**.
 - Set the time (B) at which the automation must start and tap **Next**.




4. Tap **Add task** > **Run the device** > **Micromodule Switch**.

5. Tap **Switch** on the slide-up menu select **Off(C)** and tap **Save**.



6. Tap **Next**.

7. In the **Automation Settings** page, tap **Save**.



Once the automation is saved, it is visible on the **Automation** tab. You can tap the toggle switch on the automation to enable it.

Editing an automation

To edit an automation:

1. On the **Automation** tab, locate the automation you want to edit and tap **⋮**.
2. On the **Edit** page, you can tap each item (such as dimmer, shutter, delay, temperature, etc.) to change the settings.

TIP:

- You can add one or more actions using **+**.
- To delete an existing condition or action, slide each item towards left and tap **Delete**.

Deleting an automation



To delete an automation:

1. On the **Automation** tab, locate the automation that you want to delete and then tap **⋮**.
2. Tap **Delete** and tap **Ok**.



NOTE: After deleting an automation, the device action can no longer be triggered.

LED indication

Pairing the device

| User Action | LED Indication | Status |
|--|---|--|
| Short press the setup/reset button or push button 3 times. | LED blinks orange once per second.  | Pairing mode is active for 30 seconds. When pairing is completed, LED glows green for a few seconds before turning Off.  |










Resetting the device

| User Action | LED Indication | Status |
|---|--|--|
| Short press the setup/reset button or push button 3 times and hold it down once for > 10 s. | LED blinks red once per second.  | The device is in reset mode. The device then restarts and LED turns orange indicating that the device is ready for pairing.  |

Troubleshooting

| Error | Possible cause | Solution |
|---|------------------------------------|--|
| The device is not ready to pair after the device is removed from the app. | The device is not reset correctly. | Reset to factory default settings, refer to Resetting the device manually , page 12. |

Technical data

| Nominal power rating for load type | | |
|--|--------------------------------|-------------------------|
|  | Incandescent lamp | 2200 W |
|  | Halogen lamp | 2000 W |
|  | Iron core transformer | 500 VA |
|  | Motor | 1000 VA |
|  C | Electronic step-down converter | 1050 VA 10 A, 140 µF |
|  | Fluorescent lamp | 100 W |
|  | LED | 200 W |
|  | Boiler | 2000 W |
|  | Room heater | 1500 W |

| | |
|---|--|
| Nominal voltage | AC 220-240 V, 50/60 Hz |
| Nominal current | 10 AX |
| Switching channel | 1, dry contact |
| Standby | Max. 0.3 W |
| Operating Temperature | 0 °C to 35 °C |
| Neutral conductor | Required |
| Connecting terminals | Max. 2 x 2.5 mm ² , solid or stranded types |
| Extension connection | Max. 10 mechanical push buttons |
| Length of all cable sections | Max. 50 m for 3-wire NYM cable |
| Fuse protection | 16 A circuit breaker |
| Operating frequency | 2405 - 2480 MHz |
| Max. radio-frequency power transmitted | <10 mW |
| IP rating | IP20 |
| Product dimensions (H x W x D) | 43 x 43 x 22 mm |
| Communication protocol | Zigbee 3.0 certified |

Compliance

Compliance information for Green Premium products

Find and download comprehensive information about Green Premium products, including RoHS compliance and REACH declarations as well as Product Environmental Profile (PEP) and End-of-Life instructions (EOLI).

General information about Green Premium products

Click the link below to read about Schneider Electric's Green Premium product strategy.

<https://www.schneider-electric.com/en/work/support/green-premium/>

Find compliance information for a Green Premium product

Click the link below to search for a product's compliance information (RoHS, REACH, PEP and EOLI).

NOTE: You will need the product reference number or product range to perform the search.

<https://www.reach.schneider-electric.com/CheckProduct.aspx?cskey=ot7n66yt63o1xblflyfj>

Trademarks

This guide makes reference to system and brand names that are trademarks of their relevant owners.

- Zigbee® is a registered trademark of the Connectivity Standards Alliance.
- Apple® and App Store® are brand names or registered trademarks of Apple Inc.
- Google Play™ Store and Android™ are brand names or registered trademarks of Google Inc.
- Wi-Fi® is a registered trademark of Wi-Fi Alliance®.
- Wiser™ is a trademark and the property of Schneider Electric, its subsidiaries and affiliated companies.

Other brands and registered trademarks are the property of their respective owners.

Printed in:
Schneider Electric Denmark A/S
Lautrupvang 1, 2750 Ballerup
Denmark
+45 88 30 20 00

Schneider Electric Denmark A/S
Lautrupvang 1, 2750 Ballerup

Denmark

+45 88 30 20 00

www.lk.dk

As standards, specifications, and design change from time to time,
please ask for confirmation of the information given in this publication.

© 2023 – 2023 Schneider Electric. All rights reserved.

DUG_Puck Relay_LK-00