

# Enerlin'X FDM128 Ethernet Display for Eight Devices

## FDM128 Firmware Release Notes

DOCA0151EN-03  
07/2020



# Legal Information

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this guide are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owners.

This guide and its content are protected under applicable copyright laws and furnished for informational use only. No part of this guide may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the guide or its content, except for a non-exclusive and personal license to consult it on an "as is" basis. Schneider Electric products and equipment should be installed, operated, serviced, and maintained only by qualified personnel.

As standards, specifications, and designs change from time to time, information contained in this guide may be subject to change without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this material or consequences arising out of or resulting from the use of the information contained herein.

---

# Table of Contents

|   |    |
|---|----|
| Introduction .....                              | 5  |
| FDM128 Ethernet Display for Eight Devices ..... | 5  |
| Firmware Release History .....                  | 6  |
| Firmware Update Policy .....                    | 6  |
| Firmware Update .....                           | 6  |
| Firmware Versions .....                         | 7  |
| Firmware Version 8.0.14 .....                   | 7  |
| Firmware Version 8.0.12 .....                   | 7  |
| Firmware Version 7.0.11 .....                   | 7  |
| Firmware Version 7.0.10 .....                   | 8  |
| Firmware Version 6.5.4 .....                    | 9  |
| Firmware Version 6.4.2.2 .....                  | 10 |
| Firmware Version 6.4.2 .....                    | 10 |
| Firmware Version 6.3.4 .....                    | 10 |
| Firmware Version 6.2.2 .....                    | 11 |
| Firmware Version 6.1.1 .....                    | 11 |
| Related Documents .....                         | 12 |



# Introduction

## FDM128 Ethernet Display for Eight Devices

The FDM128 Ethernet display for eight devices (LV434128) is a 1-to-8 human machine interface (HMI). The main component is a 5.7-inch touchscreen.

An FDM128 display can be connected to devices via an Ethernet interface by using any of the following options:

- One or more Ethernet gateways (IFE server, Link150, PowerLogic EGX300 and EGX100, PowerTag Link, PowerTag Link B, PowerTag Link HD, Smartlink SI B, or Smartlink Ethernet).
- One or more third-party Ethernet gateways that possess the appropriate characteristics.

The FDM128 display monitors and controls up to eight devices from the following list:

- Circuit breakers equipped with communicating MicroLogic trip units, such as:
  - MasterPact MTZ circuit breakers
  - MasterPact NT/NW circuit breakers
  - ComPact NS circuit breakers
  - ComPact NSX circuit breakers
  - PowerPact P- and R-frame circuit breakers
  - PowerPact H-, J-, and L-frame circuit breakers
- Switch-disconnectors, such as:
  - MasterPact NT HA switch-disconnectors
  - MasterPact NW NA/HA/HA10/HF switch-disconnectors
  - ComPact NS NA switch-disconnectors
  - ComPact NSX NA switch-disconnectors
  - PowerPact P- and R-frame switch-disconnectors
  - PowerPact H-, J-, and L-frame switch-disconnectors
- PowerTag Link devices, such as:
  - PowerTag Link
  - PowerTag Link B
  - PowerTag Link HD
- Smartlink devices, such as:
  - Smartlink SI B gateway
  - Smartlink Modbus gateway

The information displayed includes measures, alarms, and operating assistance data.

## Firmware Release History

| Date           | Firmware version | Availability              |
|----------------|------------------|---------------------------|
| July 2020      | 8.0.14           | Release for manufacturing |
| December 2019  | 8.0.12           | Obsolete                  |
| May 2019       | 7.0.11           | Obsolete                  |
| March 2019     | 7.0.10           | Obsolete                  |
| July 2018      | 6.5.4            | Obsolete                  |
| September 2017 | 6.4.2.2          | Obsolete                  |
| July 2017      | 6.4.2            | Obsolete                  |
| December 2016  | 6.3.4            | Obsolete                  |
| June 2016      | 6.2.2            | Obsolete                  |
| May 2015       | 6.1.1            | Obsolete                  |
| October 2014   | 5.5.6            | Obsolete                  |

## Firmware Update Policy

Firmware update is recommended to benefit from the latest features and potential bug fixes. Do not update the firmware to the latest version, if the latest features are not required for your application and no bug fixes are provided.

Use this release note to confirm if an update to the latest version of the FDM128 firmware is relevant to your application.

For more information on the firmware update policy and the firmware compatibility between devices, refer to [DOCA0155EN](#) *MicroLogic Trip and Control Units - Firmware History*.

## Firmware Update

For more information on updating the FDM128 firmware, refer to [DOCA0037EN](#) *Enerlin X FDM128 Ethernet Display for Eight Devices – User Guide*.

# Firmware Versions

## Firmware Version 8.0.14

### Bugs Fixed

- PowerTag energy sensors connected to PowerTag Link/PowerTag Link HD gateways with firmware version  $\geq 001.006.007$  were not visible in FDM128 display.
- In **Device view**, the value of current (A) in PowerTag devices was not clearly visible for Russian language.
- The details of **Alarm history** for circuit breaker devices were not displayed after navigating from the PowerTag device.
- Misalignment of display text and translation issues were existing for Chinese, Russian, and French languages.

## Firmware Version 8.0.12

### New Features

- Integrated a new device – PowerTag Link B.
- Improved the device discovery performance by 40 – 50 %.
- After every discovery loop, two options are available to discover – Gateway and Single IP, until up to eight devices are added.

### Bugs Fixed

- Status of **Breaker IO** blinked – applicable for Smartlink devices.
- Unexpected event pop-up was displayed after power off and on.
- In **General view**, the device icons were displayed one by one.
- During transition between pop-up and screens, the old screen was displayed for a moment.
- Display of updated measurement values of **Measures** submenu was delayed.
- In **General view**, the device icons were displayed as *Not Responding* state (Orange icon) for few seconds when returned from **Device view**.
- When switching between the panels, the value of THD IN blinked.
- Remote display on iOS or Android smartphone or tablet through Vijeo Design'Air app is removed due to cybersecurity risk.

## Firmware Version 7.0.11

### Bugs Fixed

- Smartlink channel configuration was lost when restarting FDM128 display.

---

## Firmware Version 7.0.10

### New Features

- Integrated the following devices:
  - PowerTag Link
  - PowerTag Link HD
  - MasterPact NT/NW switch-disconnectors
  - ComPact NSX switch-disconnectors
  - ComPact NS switch-disconnectors
  - PowerPact P- and R-frame switch-disconnectors
  - PowerPact H-, J-, and L-frame switch-disconnectors
- For all devices:
  - Allows search of devices from a different subnetwork
  - Displays **Device view** directly if only one device is selected (no **General view**)
  - Sound feedback when active area on screen is touched
- For all MicroLogic trip units and control units:
  - Added IMU location feature in **Device view**
- For MicroLogic X control unit:
  - Displays ERMS mode
  - Measures and displays THD MIN, THD MAX,  $\cos\phi$  per phase
  - Added maintenance reminder events

### Bugs Fixed

- Breaker Operation process was inconsistent with other interfaces.
- Progress message was not displayed for Breaker Operation function.
- Current and time units were inconsistent with MicroLogic trip and control units.
- Text and graphics were misaligned on FDM128 display.



## Firmware Version 6.5.4

### New Features

- Integrated the following devices:
  - PowerTag energy sensors with part numbers A9MEM1560 to A9MEM1572
  - Acti 9 OF24 indication auxiliaries
  - Acti 9 SD24 indication auxiliaries
  - PowerTag NSX energy sensors
- For all MicroLogic trip units and control units:
  - **Quick view** additionally displays ampere protection settings: Ir, Isd, Ii, Ig, and IΔn.
  - Safety message displays before opening and closing of the circuit breaker.
- For MicroLogic X control units with firmware version 002.000.003 or greater:
  - Integration of additional events.
  - **Device view** additionally displays:
    - Maintenance: load profile
    - Measures: current demand and power demand
- For ComPact NSX circuit breakers with MicroLogic 7 trip unit:
  - **Device view** additionally displays earth leakage current.
- For FDM128 display:
  - Selection of Modbus address range (between 1 and 247) before launching device discovery
  - Pre-filling of gateway and device IP addresses according to FDM128 IP address and subnetwork mask
  - Cancellation of device discovery in progress
- Real time refresh rates *Primary* and *Secondary* renamed to *Fast* and *Slow* respectively.

### Bugs Fixed

- In **General view**, status of ComPact NSX and PowerPact H-, J-, L-frame devices was unstable.
- Bar graph was inconsistent with real-time current values for PowerTag devices.
- Text and graphics on display were misaligned.

---

## Firmware Version 6.4.2.2

### Bugs Fixed

- There was access competition to the same circuit breaker on the Modbus serial line between several masters.

## Firmware Version 6.4.2

### New Features

- Integrated the following devices:
  - Acti 9 Smartlink SI D gateway
  - Enerlin'X IFM Modbus-SL interface
- For MicroLogic X control unit:
  - Integrated MTZ active alarms and alarm history

### Bugs Fixed

- In the **General view** grid, toggling of intermittent communication status resulted in unhealthy status, which is indicated in orange.
- Auto-discovery did not always function when more than nine Modbus slave devices were connected to the same master gateway.
- When IO modules were connected to a ComPact NSX circuit breaker without a BSCM installed, the **Quick view** circuit breaker status was shown as *Open*.
- For ComPact NSX circuit breaker without a BSCM installed, some pages in **Quick view** display were shown as *Not Responding* in the title bar.
- For MasterPact MTZ circuit breaker, FDM128 displayed incorrect contact wear value in maintenance page.
- For MasterPact MTZ circuit breaker, FDM128 displayed incorrect power factor value in measures page.

## Firmware Version 6.3.4

### New Features

- Integrated the following devices:
  - MasterPact MTZ circuit breakers
  - Acti 9 Smartlink SI B gateways
  - PowerTag energy sensors

## Firmware Version 6.2.2

### New Features

- Optimized scan in **General view**
- Added Refresh button to refresh IMU names and Smartlink names
- Removed date and time
- Added Turkish language

## Firmware Version 6.1.1

### New Features

- Added RBAC access management with three levels: Guest, Operator, and Administrator
- Added the following communication settings:
  - Extended auto-discovery from single gateway to several gateways
  - Manual addition of additional single IP devices from **General view**
  - Communication settings displayed from **General view**
- Added IMU location feature
- Added Czech language

## Related Documents

The following table lists the documents that are compatible with a FDM128 display with the latest firmware version:

| Title of documentation  | Publication date | Reference number   |
|---|------------------|--|
| <i>Enerlin<sup>™</sup> X FDM128 Ethernet Display for Eight Devices – User Guide</i> | 12/2019          | <a href="#">DOCA0037EN-08</a><br><a href="#">DOCA0037ES-08</a><br><a href="#">DOCA0037FR-08</a><br><a href="#">DOCA0037ZH-08</a> |

You can download these technical publications and other technical information from the website at <https://www.se.com/en/download>.



Schneider Electric  
35 rue Joseph Monier  
92500 Rueil Malmaison  
France

+ 33 (0) 1 41 29 70 00

[www.se.com](http://www.se.com)

As standards, specifications, and design change from time to time,  
please ask for confirmation of the information given in this publication.

© 2020 – Schneider Electric. All rights reserved.

DOCA0151EN-03